



# **XCITING 300i**

# **TRAINING MATERIALS**

Made by: David

Made up by: Michael

Date: 2008.09.08

# SPECIFICATIONS XCITING 300i

## ENGINE

Bore and stroke  
Compression ratio  
Displacement  
Spark plug  
Standard (XCITING 300 AFI)  
Idle speed

72.7 X65.2 mm  
10.6:1  
 $270 \text{ cm}^3$

## CHASSIS TRANSMISSION

Tire size, front  
Tire size, rear

## XCITING 300 AFI

1500~1700 min<sup>-1</sup> (rpm)

## ELECTRICAL


Battery  
Headlight  
Tail/brake light  
Turn signal light  
Position light  
Fuse  
Main fuse  
Other fuses

120/70-15  
150/70-14

## XCITING 300i

12V-12 Ah  
12V60W/12V55W  
LEDX45(12V0.47W)/LEDX45(12V4.4W)  
12V10W X 4  
12V5W(front)/LEDX45(12V0.47W)  
Fuse  
Main fuse  
Other fuses

# KEIHIN FIS SYSTEM LAYOUT



No.	FULL NAME	ABBREVIATIONS
(01)	Electrical control unit	ECU
(02)	Tilt switch	ROLL
(03)	Fuel pump	FP
(04)	Water temperature sensor	WTS sensor
(05)	Crank position sensor	CPS
(06)	Oxygen sensor	O2 sensor
(07)	Air idle speed valve (Secondary air valve)	AISV
(08)	Inductive ignition coil	IG
(09)	Fuel injector	INJ
(10)	Intake pressure sensor	MAP sensor
(11)	Idle air bypass valve	ISC
(12)	Throttle position sensor	TPS

# XCITING 300i PARTS LOCATION



No 1

\*But for 500i, ECU is located under the front cover.




No 2



No 5  
No 6



- No 1: ECU( for 300i)
- No 2: Tilt switch
- No 3: Fuel pump
- No 4: WTS sensor
- No 5: CPS
- No 6: O2 sensor
- No 7: AISV
- No 8: IG
- No 9: INJ
- No 10: MAP sensor
- No 11: ISC
- No 12: TPS

# XCITING 300i PARTS LOCATION



- No 1: ECU
- No 2: Tilt switch
- No 3: Fuel pump
- No 4: WTS sensor
- No 5: CPS
- No 6: O2 sensor
- No 7: AISV
- No 8: IG
- No 9: INJ
- No 10: MAP sensor
- No 11: ISC
- No 12: TPS


# SELF-DIAGNOSTIC PROCEDURES



1. Turn key to On position
2. The engine check indicator light will blink twice.

# FAILURE CODES READ ON THE CELP INDICATOR

Put the side stand up and  
engine stop switch is at "RUN"



# DTC FAILURE CODES LIST

Blinks (Fi tool)	Failure Codes (PDA)	Contents	Causes	Symptoms
06	P0120	Faulty TPS	<ul style="list-style-type: none"> <li>· TPS range fault</li> <li>· Eoose or poor contacts on TPS Sensor</li> <li>· Open or short circuit in TPS wire</li> <li>· Faulty TPS</li> </ul>	<ul style="list-style-type: none"> <li>· Engine operates normally</li> </ul>
09	P0105	Faulty MAP	<ul style="list-style-type: none"> <li>· Eoose or poor contacts on MAP</li> <li>· Open or short circuit in MAP wire</li> <li>· Faulty MAP</li> </ul>	<ul style="list-style-type: none"> <li>· Engine operates normally</li> </ul>
11	P0195	Faulty ECT (oil temperature)	<ul style="list-style-type: none"> <li>· Eoos this equipment</li> </ul>	
12	P0115	Faulty WTS (water temperature)	<ul style="list-style-type: none"> <li>· Eoose or poor contacts on WTS</li> <li>· Open or short circuit in WTS wire</li> <li>· Faulty WTS</li> </ul>	<ul style="list-style-type: none"> <li>· Engine operates normally</li> </ul>

# DTC FAILURE CODES LIST

13	P0110	Faulty IAT	<ul style="list-style-type: none"> <li>! No this equipment</li> <li>! Eoose or poor contacts on tilt switch</li> <li>! Open or short circuit in tilt switch wire</li> <li>! Faulty tilt switch</li> </ul>	<ul style="list-style-type: none"> <li>! Engine operates normally</li> </ul>
15	P1630	Faulty Tilt switch (Roll)	<ul style="list-style-type: none"> <li>! Eoose or poor contacts on O2 sensor</li> <li>! Open or short circuit in O2 sensor wire</li> <li>! Faulty O2 sensor</li> </ul>	<ul style="list-style-type: none"> <li>! Engine operates normally</li> </ul>
17	P0130	Faulty O2 sensor	<ul style="list-style-type: none"> <li>! Eoose or poor contacts on injector</li> <li>! Open or short circuit in injector wire</li> <li>! Faulty fuel injector</li> </ul>	<ul style="list-style-type: none"> <li>! Engine does not start</li> <li>! Engine does not operate</li> </ul>
33	P0201	Faulty injector (Nozzle)		


# DTC FAILURE CODES LIST

Blinks (Fi tool)	Failure Codes (PDA)	Contents	Causes	Symptoms
37	P0351	Faulty inductive ignition coil	<ul style="list-style-type: none"> <li>• Loose or poor contacts on inductive ignition coil</li> <li>• Open or short circuit in inductive ignition coil wire</li> <li>• Faulty inductive ignition coil</li> </ul>	<ul style="list-style-type: none"> <li>• Engine does not start</li> <li>• Engine does not operate</li> </ul>
41	P0230	Faulty fuel pump	<ul style="list-style-type: none"> <li>• Loose or poor contacts on fuel pump</li> <li>• Open or short circuit in fuel pump wire</li> <li>• Faulty fuel pump</li> </ul>	<ul style="list-style-type: none"> <li>• Engine does not start</li> <li>• Engine does not operate</li> </ul>
45	P0135	Faulty O <sub>2</sub> sensor heater	<ul style="list-style-type: none"> <li>• Loose or poor contacts on O<sub>2</sub> sensor heater</li> <li>• Open or short circuit in O<sub>2</sub> sensor heater wire</li> <li>• Faulty O<sub>2</sub> sensor heater</li> </ul>	<ul style="list-style-type: none"> <li>• Engine starts normally</li> <li>• Engine does not operate</li> </ul>


# DTC FAILURE CODES LIST

Blinks (Fi tool)	Failure Codes (PDA)	Contents	Causes	Symptoms
49	P1505	Faulty ISC	<ul style="list-style-type: none"> <li>; Eoose or poor contacts on ISC</li> <li>; Open or short circuit in ISC wire</li> <li>; Fauly ISC</li> </ul>	<ul style="list-style-type: none"> <li>; Engine operates normally</li> </ul>
54	P1410	Faulty AISV	<ul style="list-style-type: none"> <li>; Eoose or poor contacts on AISV</li> <li>; Open or short circuit in AISV wire</li> <li>; Fauly AISV</li> </ul>	<ul style="list-style-type: none"> <li>; Engine operates normally</li> </ul>
66	P0335	Faulty CPS	<ul style="list-style-type: none"> <li>; Eoose or poor contacts on CPS</li> <li>; Open or short circuit in CPS wire</li> <li>; Fauly CPS</li> </ul>	<ul style="list-style-type: none"> <li>; Engine does not start</li> <li>; Engine does not operate</li> </ul>

# FAILURE CODES RESET PROCEDURES




# RESET TPS/ISC PROCEDURE



## RECHECK TPS/ISC WITH FI DIAGNOSTIC TOOL

1. Turn to page 2 on Fi diagnostic tool
2. Release the throttle
3. Refer to standard specifications as below,  
“ Throttle position ” : 1% below  
“ Throttle position sensor output voltage ” :  $0.5 \pm 0.10$  Volt.




## RECHECK TPS/ISC WITH Fi DIAGNOSTIC TOOL

1. Fully open the throttle.
2. Refer to standard specifications as below,  
“Throttle position (TP)”: 96% over  
“Throttle position sensor output voltage”: 3.5--3.9 Volt.



# Fi DIAGNOSTIC TOOL CONNECTION


1. Upward the side stand
2. Turn the engine stop switch to the “RUN” position



Diagnostic Tool Connector



RUN




Upward side stand

## THROTTLE BODY/MAP/TPS/ISC REMOVAL / INSTALLATION

TPS and ISC have to be reset after the throttle body MAP, TPS, ISC or ECU has been reinstalled.



ISC seat




Remove the screw of the ISC seat.  
Carefully install the ISC and seat into the hole of throttle body after using the engine oil onto the O-ring.

## THROTTLE BODY/MAP/ISC REMOVAL / INSTALLATION

Remove the screw of the MAP.

Carefully install the MAP into the hole of throttle body after using the engine oil onto the O-ring.

MAP



# Clean the THROTTLE BODY


1. Remove the throttle body.
2. Use the carburetor cleaner to clean the throttle body's butterfly valve.
3. Waiting for ten minutes.
4. Blow the throttle body with a air gun.
5. Install the throttle body.



# FUEL PUMP REMOVAL / INSTALLATION

## REMOVAL

1. Disconnect the connector and fuel band from the fuel pump.
2. Remove the six screws onto the fuel pump.
3. Remove the fuel pump and O-ring.



Hose band  
Screw  
Connector

## INSTALLATION

1. Replace a new O-ring on the fuel tank.
2. Be careful not to damage the fuel pump wire and ensure the connector rearward.
3. Tighten the six screws.



O-ring


# FUEL PRESSURE INSPECTION

1. Turn the key to the OFF position.
2. Use the fuel hose clamp.
3. Disconnect the fuel hose from the fuel injector.
4. Connect the fuel pressure gauge.
5. Turn the key to the ON position.
5. Check the fuel pressure. **Standard:3.0 Bar**



## Caution


If the fuel pressure is less than three bar, may fail to start the engine or in trouble in case of riding.




# FUEL INJECTOR REMOVAL / INSTALLATION

## REMOVAL

1. Disconnect the connector from the fuel injector.
2. Remove the bolt of the fuel injector.
3. Take out of the fuel pipe and fuel injector from the Inlet pipe.
4. Remove the fuel injector from the fuel pipe



Bolt  
Connector



O-ring

## Caution

Ensure the fuel pipe without any pressure, then remove the fuel injector.

STEP 1 : Disconnect the fuel pump relay or fuel pump connector.

STEP 2: Turn the key to the ON position. Starting the engine till the engine stop working.

# FUEL INJECTOR REMOVAL / INSTALLATION

## INSTALLATION

1. Apply the engine oil to a new O-ring.
2. Install the fuel injector into the fuel pipe.
3. Ensure the tab of the fuel injector inserted into the groove of the fuel pipe.

Groove



Tab



Dowel pin  
O-ring

4. Install the fuel pipe into the intake manifold by aligning the dowel pin.
5. Be careful not to damage the O-ring.
6. Tighten the fuel pipe mounting bolt.

# FUEL INJECTOR CLEANING PROCEDURE

## Problem:

1. Fuel Injector cannot output the fuel.
2. The Fuel injector operation time (ms) is shorter or longer.

**Standard: less than 1.6ms**

## Analysis:

Injector block (With some carbons).

## Troubleshooting:

1. Use the specified injector cleaner.
2. Pouring the liquid of carburetor cleaner until half container .
3. Connect the battery as picture.
4. The injector cleaner with the flash relay.
5. Keeping the fuel Injector operation.
6. Waiting for 20-30 minutes.
7. Cleaning the carbons completely.

Battery

Fuel Injector

Container

Flash relay

# EMS PARTS INSPECTION SPECIFICATIONS

NO.	Part Name	Drawing	INSPECTION WAY	Item	Specification	Remark	Temperature
1.	ECU		V PDA Multimeter	1. Outlook checking 2. Performance confirmed 3. Voltage inspection 4. MAP content(edition issue no.)	1. Confirm by drawing chart code 2. Connection for Harness and wire connector 3. Voltage = $5V \pm 0.1V$ 4. Follow the diagnosis record list	-15¢ ƒ70¢ J	
2.	IDLE AIR BYPASS VALVE (ISC)		V	1. Air leak test (low and high pressure) 2. Opening setting 3. Confirm if performance is smooth 4. Outlook (with joint)	1. Low pressure: 49kpa ( $0.5kg/cm^2$ ) High pressure: 343kpa ( $3.5kg/cm^2$ ) 2. IDLE opening: $0.6V \pm 0.02V$ WOT opening: $3.77V$ 3. Confirm if performance is smooth? 4. Confirm if outlook is broken (with joint)?	-15¢ ƒ120¢ J	
3.	MAP SENSOR		V	V	V	-15¢ ƒ60¢ J	Resistance: 3500~6500Ω Voltage: 0°~105° (0.3~4.5V) 5KΩ ±30%
4.	THROTTLE POSITION SENSOR (TPS)		V	V	V	-30¢ ƒ110¢ J	

				<b>5.</b> FUEL PUMP	V  V	V  V	V  V	V  V	1. Leakage test 2. Outlook (with joint) 3. Insulation resistance 4. Leakage test for Fuel tube 5. Noisy 6. FUEL LEVEL	1. Leakage= 3.92kpa (0.4kg/cm <sup>2</sup> ) 2. No rust and damaged 3. >1MΩ [ 4. Leakage= 343kpa (3.5kg/cm <sup>2</sup> ) 5. Noisy? 6. FUEL LEVEL F:7Ω #3 E:95Ω [ ±5	1. Leakage= 3.92kpa (0.4kg/cm <sup>2</sup> ) 2. No rust and damaged 3. >1MΩ [ 4. Leakage= 343kpa (3.5kg/cm <sup>2</sup> ) 5. Noisy? 6. FUEL LEVEL F:7Ω #3 E:95Ω [ ±5	1. Leakage= 3.92kpa (0.4kg/cm <sup>2</sup> ) 2. No rust and damaged 3. >1MΩ [ 4. Leakage= 343kpa (3.5kg/cm <sup>2</sup> ) 5. Noisy? 6. FUEL LEVEL F:7Ω #3 E:95Ω [ ±5	1. Leakage= 3.92kpa (0.4kg/cm <sup>2</sup> ) 2. No rust and damaged 3. >1MΩ [ 4. Leakage= 343kpa (3.5kg/cm <sup>2</sup> ) 5. Noisy? 6. FUEL LEVEL F:7Ω #3 E:95Ω [ ±5	1. Leakage= 3.92kpa (0.4kg/cm <sup>2</sup> ) 2. No rust and damaged 3. >1MΩ [ 4. Leakage= 343kpa (3.5kg/cm <sup>2</sup> ) 5. Noisy? 6. FUEL LEVEL F:7Ω #3 E:95Ω [ ±5	1. Leakage= 3.92kpa (0.4kg/cm <sup>2</sup> ) 2. No rust and damaged 3. >1MΩ [ 4. Leakage= 343kpa (3.5kg/cm <sup>2</sup> ) 5. Noisy? 6. FUEL LEVEL F:7Ω #3 E:95Ω [ ±5	1. Leakage= 3.92kpa (0.4kg/cm <sup>2</sup> ) 2. No rust and damaged 3. >1MΩ [ 4. Leakage= 343kpa (3.5kg/cm <sup>2</sup> ) 5. Noisy? 6. FUEL LEVEL F:7Ω #3 E:95Ω [ ±5
			<b>6.</b> FUEL INJECTOR	V  V	V  V	V  V	V  V	1. Flow rate 2. Resistance Value	1. Follow the KTW final inspection list. 2. 9.945~13.5Ω [ ±5	1. Follow the KTW final inspection list. 2. 9.945~13.5Ω [ ±5	1. Follow the KTW final inspection list. 2. 9.945~13.5Ω [ ±5	1. Follow the KTW final inspection list. 2. 9.945~13.5Ω [ ±5	1. Follow the KTW final inspection list. 2. 9.945~13.5Ω [ ±5	1. Follow the KTW final inspection list. 2. 9.945~13.5Ω [ ±5		
	<b>7.</b> WATER TEMPERATURE SENSOR (WTS)	V  V	V  V	V  V		1. Resistance Value 2. Insulation resistance	-20°C ~ 18.8°C [ +40°C ~ 1.136KΩ [ +100°C ~ 0.1553KΩ [	1. Resistance Value 2. Insulation resistance	-20°C ~ 18.8°C [ +40°C ~ 1.136KΩ [ +100°C ~ 0.1553KΩ [	1. Resistance Value 2. Insulation resistance	1. Resistance Value 2. Insulation resistance	1. Resistance Value 2. Insulation resistance				
				<b>8.</b> INDUCTIVE IGNITION COIL	V  V	V  V	V  V	V  V	1. Resistance Value	Primary: 3.57 ~ 4.83Ω [ Secondary: 10.42~14.49KΩ [ ±5	1. Resistance Value	4.2±15%	12.6±15%	-15°C ~ +60°C J	-15°C ~ +60°C J	

9. OXYGEN SENSOR	V	V	V	1. Resistance Value 2. Output voltage 3. Outlook	1. Heater resistance : 6.7€ [9.5€] 2. Sensor output voltage : A/F: < when 14.7, > 0.8V(RICH) A/F: > when 14.7, < 0.18V(LEAN) 3. Confirm outlook no rust and damaged. 4. Confirm length of protect tube	Heater: 6.7€ [9.5€] Measure after the engine is warm
0. CRANK POSITION SENSOR (CPS)	V	V	V	1. Resistance Value	Resistance: 100~130Ω	115Ω [15Ω] -15Ω [130Ω]
1. AIR INJECTION SOLENOID VALVE	V	V	V	1. Resistance Value	Resistance: 25.95~29.55Ω	-20Ω [80Ω]
2. TILT SWITCH	V	V	V	1. Output voltage at normal 2. Output voltage when the vehicle fall down	1. Normal = 0.4V~1.4V 2. Fall down = 3.7V~4.4V	-20Ω [80Ω]

**Thank you for your attendance**

