

## PREFACE

This Service Manual describes the technical features and servicing procedures for the KYMCO

### ***SUPER 8 50***

Section 1 contains the precautions for all operations stated in this manual. Read them carefully before starting any operation.

Section 2 is the removal/installation procedures for the frame covers which are subject to higher removal/installation frequency during maintenance and servicing operations.

Section 3 describes the inspection/adjustment procedures, safety rules and service information for each part, starting from periodic maintenance.

Sections 6 through 17 give instructions for disassembly, assembly and inspection of engine, chassis frame and electrical equipment.

Most sections start with an assembly or system illustration and troubleshooting for the section. The subsequent pages give detailed procedures for the section.

Our company reserves the right to make any alteration in the design. The information and contents included in this manual may be different from the motorcycle in case specifications are changed.

## TABLE OF CONTENTS

|                      |                                          |    |
|----------------------|------------------------------------------|----|
| ENGINE               | GENERAL INFORMATION                      | 1  |
|                      | FRAME COVERS/EXHAUST MUFFLER             | 2  |
|                      | INSPECTION/ADJUSTMENT                    | 3  |
|                      | LUBRICATION SYSTEM                       | 4  |
|                      | FUEL SYSTEM                              | 5  |
|                      | ENGINE REMOVAL/INSTALLATION              | 6  |
|                      | CYLINDER HEAD/VALVES                     | 7  |
|                      | CYLINDER/PISTON                          | 8  |
|                      | DRIVE AND DRIVEN PULLEYS                 | 9  |
|                      | FINAL REDUCTION                          | 10 |
|                      | CRANKCASE/CRANKSHAFT                     | 11 |
| CHASSIS              | FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION | 12 |
|                      | REAR WHEEL /REAR BRAKE /REAR SUSPENSION  | 13 |
| ELECTRICAL EQUIPMENT | BATTERY/CHARGING SYSTEM/A.C. GENERATOR   | 14 |
|                      | IGNITION SYSTEM                          | 15 |
|                      | STARTING SYSTEM                          | 16 |
|                      | LIGHTS/INSTRUMENTS/SWITCHES              | 17 |
|                      | EXHAUST EMISSION CONTROL SYSTEM          | 18 |

**KWANG YANG MOTOR CO., LTD.**  
**OVERSEAS SALES DEPARTMENT**  
**OVERSEAS SERVICE SECTION**

# 1. GENERAL INFORMATION

**SUPER 8 50**

**1**

|                            |      |                              |      |
|----------------------------|------|------------------------------|------|
| ENGINE SERIAL NUMBER ..... | 1- 1 | LUBRICATION POINTS.....      | 1-13 |
| SPECIFICATIONS.....        | 1- 2 | CABLE & HARNESS ROUTING..... | 1-15 |
| SERVICE PRECAUTIONS .....  | 1- 3 | WIRING DIAGRAM .....         | 1-20 |
| TORQUE VALUES .....        | 1-11 | TROUBLESHOOTUNG.....         | 1-21 |
| SPECIAL TOOLS .....        | 1-12 |                              |      |

## ENGINE SERIAL NUMBER

Frame Serial Number



Location of Engine Serial Number

# 1. GENERAL INFORMATION

## SPECIFICATIONS

|                        |                                                |                  |                            |                      |  |  |
|------------------------|------------------------------------------------|------------------|----------------------------|----------------------|--|--|
| Motorcycle Name & Type |                                                |                  | SUPER 8 50                 |                      |  |  |
| Name & Model No.       |                                                |                  | KP10G(BLA2)                |                      |  |  |
| Overall length (mm)    |                                                |                  | 2040                       |                      |  |  |
| Overall width (mm)     |                                                |                  | 735                        |                      |  |  |
| Overall height (mm)    |                                                |                  | 1100                       |                      |  |  |
| Wheel base (mm)        |                                                |                  | 1365                       |                      |  |  |
| Engine type            |                                                |                  | Air cooled 4-stroke        |                      |  |  |
| Displacement           |                                                |                  | 50cc                       |                      |  |  |
| Fuel Used              |                                                |                  | 92# nonleaded gasoline     |                      |  |  |
| Net weight (kg)        |                                                | Front wheel      | 47                         |                      |  |  |
|                        |                                                | Rear wheel       | 73                         |                      |  |  |
|                        |                                                | Total            | 120                        |                      |  |  |
| Max weight(kg)         |                                                | Front wheel      | 87                         |                      |  |  |
|                        |                                                | Rear wheel       | 183                        |                      |  |  |
|                        |                                                | Total            | 270                        |                      |  |  |
| Tires                  |                                                | Front wheel      | 120/70 -14                 |                      |  |  |
|                        |                                                | Rear wheel       | 120/80 -14                 |                      |  |  |
| Ground clearance (mm)  |                                                |                  | 130                        |                      |  |  |
| Perform-<br>ance       | Braking distance (m)                           |                  | 2.0 (Initial speed 30km/h) |                      |  |  |
|                        | Min. turning radius (mm)                       |                  | L:2060/R:2050              |                      |  |  |
| Engine                 | Starting system                                |                  | Starting motor             |                      |  |  |
|                        | Type                                           |                  | Gasoline, 4-stroke         |                      |  |  |
|                        | Cylinder arrangement                           |                  | Single cylinder            |                      |  |  |
|                        | Combustion chamber type                        |                  | Semi-sphere                |                      |  |  |
|                        | Valve arrangement                              |                  | O.H.C.                     |                      |  |  |
|                        | Bore x stroke (mm)                             |                  | φ 39*41.4                  |                      |  |  |
|                        | Compression ratio                              |                  | 11.2:1                     |                      |  |  |
|                        | Compression pressure (kg/cm <sup>2</sup> -rpm) |                  | 12±2                       |                      |  |  |
|                        | Max. output                                    |                  | 2.3kw/7000rpm              |                      |  |  |
|                        | Max. torque                                    |                  | 3.3Nm/6000rpm              |                      |  |  |
|                        | Port timing                                    | Intake           | Open                       | -10°                 |  |  |
|                        |                                                |                  | Close                      | 17°                  |  |  |
|                        |                                                | Exhaust          | Open                       | 30°                  |  |  |
|                        |                                                |                  | Close                      | -8°                  |  |  |
|                        | Valve clearance (cold) (mm)                    |                  | Intake                     | 0.10                 |  |  |
|                        |                                                |                  | Exhaust                    | 0.10                 |  |  |
|                        | Idle speed (rpm)                               |                  |                            | 2000rpm              |  |  |
|                        | Lubricatio<br>n System                         | Lubrication type |                            | OIL PUMP             |  |  |
|                        |                                                | Oil pump type    |                            | Cycloid type         |  |  |
|                        |                                                | Oil filter type  |                            | Full-flow filtration |  |  |
|                        |                                                | Oil capacity     |                            | 0.85 liter           |  |  |
| Cooling Type           |                                                |                  | Forced air cooling         |                      |  |  |


|                      |                                     |                   |                                 |                        |                     |  |
|----------------------|-------------------------------------|-------------------|---------------------------------|------------------------|---------------------|--|
| Fuel System          | Air cleaner type & No               |                   |                                 | Paper element          |                     |  |
|                      | Fuel capacity                       |                   |                                 | 6.0 liter              |                     |  |
|                      | Carburetor                          | Type              |                                 | -----                  |                     |  |
|                      |                                     | Piston dia. (mm)  |                                 | -----                  |                     |  |
|                      |                                     | Venturi dia.(mm)  |                                 | --                     |                     |  |
| Throttle type        |                                     |                   |                                 |                        |                     |  |
| Electrical Equipment | Ignition System                     | Type              |                                 | ECU                    |                     |  |
|                      |                                     | Ignition timing   |                                 | BTDC 13 °~ 28 °        |                     |  |
|                      |                                     | Contact breaker   |                                 | Non-contact point type |                     |  |
|                      |                                     | Spark plug        |                                 | NGK CR6HSA             |                     |  |
|                      |                                     | Spark plug gap    |                                 | 0.6~0.7mm              |                     |  |
|                      | Battery                             | Capacity          |                                 | 12V8AH                 |                     |  |
| Power Drive System   | Clutch                              | Type              |                                 | Dry centrifugal type   |                     |  |
|                      |                                     | Transmission Gear | Type                            |                        | CVT                 |  |
|                      | Operation                           |                   | Stepless automatic transmission |                        |                     |  |
|                      | Reduction Gear                      |                   | Type                            |                        | Two-stage reduction |  |
|                      |                                     |                   | Reduction ratio                 | 1st                    | 0.8-3.1             |  |
|                      |                                     | 2nd               |                                 | 11.05                  |                     |  |
| Moving Device        | Front Axle                          | Caster angle      |                                 | 27°                    |                     |  |
|                      |                                     | Trail length      |                                 | —                      |                     |  |
|                      | Tire pressure (kg/cm <sup>2</sup> ) |                   | Front                           | 1.75                   |                     |  |
|                      |                                     |                   | Rear                            | 2.25                   |                     |  |
|                      | Turning angle                       |                   | Left                            | 45°                    |                     |  |
|                      |                                     |                   | Right                           | 45°                    |                     |  |
|                      | Brake system type                   |                   |                                 | Front                  | DISK                |  |
|                      |                                     |                   | Rear                            | Drum                   |                     |  |
| Damping Device       | Suspension type                     |                   | Front                           | FR:TELESCOPE           |                     |  |
|                      |                                     |                   | Rear                            | RR:UNIT SWING          |                     |  |
|                      | Shock absorber distance             |                   | Front                           | 80                     |                     |  |
|                      |                                     |                   | Rear                            | 82                     |                     |  |
| Frame type           |                                     |                   |                                 | Pipe Under Bone        |                     |  |

# 1. GENERAL INFORMATION


**SUPER 8 50**

## SERVICE PRECAUTIONS


- Make sure to install new gaskets, O-rings, circlips, cotter pins, etc. when reassembling.




- When tightening bolts or nuts, begin with larger-diameter to smaller ones at several times, and tighten to the specified torque diagonally.




- Use genuine parts and lubricants



- When servicing the motorcycle, be sure to use special tools for removal and installation.




- After disassembly, clean removed parts. Lubricate sliding surfaces with engine oil before reassembly.






# 1. GENERAL INFORMATION


- Apply or add designated greases and lubricants to the specified lubrication points.




- After reassembly, check all parts for proper tightening and operation.




- When two persons work together, pay attention to the mutual working safety.



- Disconnect the battery negative (-) terminal before operation.
- When using a spanner or other tools, make sure not to damage the motorcycle surface.




- After operation, check all connecting points, fasteners, and lines for proper connection and installation.
- When connecting the battery, the positive (+) terminal must be connected first.
- After connection, apply grease to the battery terminals.
- Terminal caps shall be installed securely.




# 1. GENERAL INFORMATION


- If the fuse is burned out, find the cause and repair it. Replace it with a new one according to the specified capacity.



- After operation, terminal caps shall be installed securely.




- When taking out the connector, the lock on the connector shall be released before operation.



- Hold the connector body when connecting or disconnecting it.
- Do not pull the connector wire.




- Check if any connector terminal is bending, protruding or loose.




# 1. GENERAL INFORMATION


- The connector shall be inserted completely.
- If the double connector has a lock, lock it at the correct position.
- Check if there is any loose wire.




- Before connecting a terminal, check for damaged terminal cover or loose negative terminal.




- Check the double connector cover for proper coverage and installation.



- Insert the terminal completely.
- Check the terminal cover for proper coverage.
- Do not make the terminal cover opening face up.




- Secure wire harnesses to the frame with their respective wire bands at the designated locations. Tighten the bands so that only the insulated surfaces contact the wire harnesses.



# 1. GENERAL INFORMATION

**SUPER 8 50**


- After clamping, check each wire to make sure it is secure.




- Do not squeeze wires against the weld or its clamp




- After clamping, check each harness to make sure that it is not interfering with any moving or sliding parts.



- When fixing the wire harnesses, do not make it contact the parts which will generate high heat.




- Route wire harnesses to avoid sharp edges or corners. Avoid the projected ends of bolts and screws.
- Route wire harnesses passing through the side of bolts and screws. Avoid the projected ends of bolts and screws.




# 1. GENERAL INFORMATION


- Route harnesses so they are neither pulled tight nor have excessive slack.




- Protect wires and harnesses with electrical tape or tube if they contact a sharp edge or corner



- When rubber protecting cover is used to protect the wire harnesses, it shall be installed securely.



- Do not break the sheath of wire.
- If a wire or harness is with a broken sheath, repair by wrapping it with protective tape or replace it.




- When installing other parts, do not press or squeeze the wires.




# 1. GENERAL INFORMATION

**SUPER 8 50**


- After routing, check that the wire harnesses are not twisted or kinked.



- Wire harnesses routed along with handlebar should not be pulled tight, have excessive slack or interfere with adjacent or surrounding parts in all steering positions.




- When a testing device is used, make sure to understand the operating methods thoroughly and operate according to the operating instructions.




- Be careful not to drop any parts.

- When rust is found on a terminal, remove the rust with sand paper or equivalent before connecting.



- Do not bend or twist control cables. Damaged control cables will not operate smoothly and may stick or bind.



# 1. GENERAL INFORMATION

---

## ■ Symbols:

The following symbols represent the servicing methods and cautions included in this service manual.



Engine Oil

: Apply engine oil to the specified points. (Use designated engine oil for lubrication.)



Grease

: Apply grease for lubrication.



Gear Oil

: Transmission Gear Oil (90#)



: Use special tool.



: Caution



: Warning

(⇒12-3) : Refer to page 12-3.

# 1. GENERAL INFORMATION

**SUPER 8 50**

## TORQUE VALUES

### STANDARD TORQUE VALUES

| Item           | Torque (kg-m) | Item                  | Torque (kg-m) |
|----------------|---------------|-----------------------|---------------|
| 5mm bolt, nut  | 0.45-0.6      | 5mm screw             | 0.35-0.5      |
| 6mm bolt, nut  | 0.6-1.2       | 6mm screw, SH bolt    | 0.7-1.1       |
| 8mm bolt, nut  | 1.8-2.5       | 6mm flange bolt, nut  | 1.0-1.4       |
| 10mm bolt, nut | 3.0-4.0       | 8mm flange bolt, nut  | 2.4-3.0       |
| 12mm bolt, nut | 5.0-6.0       | 10mm flange bolt, nut | 3.5-4.5       |

Torque specifications listed below are for important fasteners.

### ENGINE

| Item                             | Q'ty | Thread dia.(mm) | Torque (kg-m) | Remarks                                     |
|----------------------------------|------|-----------------|---------------|---------------------------------------------|
| Cylinder head bolt A             | 2    | 6               | 0.7-1.1       | Double end bolt<br><br>Apply oil to threads |
| Cylinder head bolt B             | 4    | 6               | 0.7-1.1       |                                             |
| Oil filter screen cap            | 1    | 30              | 1.0-2.0       |                                             |
| Exhaust muffler lock bolt        | 2    | 6               | 0.7-1.1       |                                             |
| Cylinder head flange nut         | 4    | 7               | 1.2-1.6       |                                             |
| Valve adjusting lock nut         | 2    | 3               | 0.07-0.09     |                                             |
| Cam chain tensioner slipper bolt | 1    | 8               | 0.4-0.7       |                                             |
| Oil bolt                         | 1    | 8               | 1.1-1.5       |                                             |
| Clutch outer nut                 | 1    | 10              | 3.5-4.5       |                                             |
| Clutch drive plate nut           | 1    | 28              | 5.0-6.0       |                                             |
| Starter motor mounting bolt      | 2    | 6               | 0.8-1.2       |                                             |
| Oil pump bolt                    | 3    | 4               | 0.1-0.3       |                                             |
| Drive face nut                   | 1    | 10              | 5.5-6.5       |                                             |
| Spark plug                       | 1    | 10              | 1.0-1.4       |                                             |
| A.C. generator stator bolt       | 2    | 6               | 0.8-1.2       |                                             |
| Cam chain tensioner bolt         | 1    | 6               | 0.8-1.2       |                                             |

### FRAME

| Item                           | Q'ty | Thread dia.(mm) | Torque (kg-m) | Remarks             |
|--------------------------------|------|-----------------|---------------|---------------------|
| Steering stem lock nut         | 1    | 25.4            | 8.0-12.0      | U-nut               |
| Front axle nut                 | 1    | 10              | 5.0-7.0       | U-nut               |
| Rear axle nut                  | 1    | 14              | 11.0-13.0     | U-nut               |
| Rear shock absorber upper bolt | 1    | 10              | 4.0-5.0       |                     |
| Rear shock absorber lower bolt | 1    | 8               | 2.0-3.0       |                     |
| Speedometer cable set screw    | 1    | 5               | 0.45-0.6      |                     |
| Rear shock absorber lock nut   | 1    | 8               | 3.0-3.6       | Apply locking agent |



# 1. GENERAL INFORMATION

SUPER 8 50

## SPECIAL TOOLS

| Tool Name                           | Tool No. | Remarks                                     | Ref. Page                          |
|-------------------------------------|----------|---------------------------------------------|------------------------------------|
| Bearing puller 10.12.15.18 mm       | E037     | 10.12.15.18mm bearing                       | 10-3<br>10-4<br>12-6               |
| Bushing remover L                   | E032     | 11102 bush engine hanger rubber             |                                    |
| Bushing remover S                   | EO19     | 11203 bush rear cushion under rubber        |                                    |
| Crankshaft bearing puller           | E030     | 91005 radial bearing                        |                                    |
| Crankshaft protector                | E029     | 13000 crankshaft comp 12mm.14mm             |                                    |
| Clutch spring compressor            | E027     | 2301a driven pully assy                     | 9-9<br>9-12                        |
| Cushion assemble & disassemble tool | F004     | 52400 cushion assy                          | 13-4                               |
| Flywheel holder                     | E017     | 31110 flywheel comp.2310a pully assy driven | 9-5<br>9-9<br>9-13<br>14-7<br>14-9 |
| Flywheel puller                     | E002     | Left hand thread 27mm                       | 14-7                               |
| Long socket wrench 32mm 8angle      | F002     | 50306 steering stem                         | 12-21<br>12-22                     |
| Oil seal & bearing installer        | E014     | Oil seal & bearing install                  |                                    |
| Tool boox                           | E033     | Special tools storage                       |                                    |
| Tappet adjuster                     | E036     | 90012 screw tappet                          | 3-5                                |
| Valve spring compressor             | E038     | Valve spring                                | 7-7<br>7-8                         |

# 1. GENERAL INFORMATION

**SUPER 8 50**

## LUBRICATION POINTS

### ENGINE

| Lubrication Points                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | Lubricant                                                                                                           |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
| Valve guide/valve stem movable part<br>Cam lobes<br>Valve rocker arm friction surface<br>Cam chain<br>Cylinder lock bolt and nut<br>Piston surroundings and piston ring grooves<br>Piston pin surroundings<br>Cylinder inside wall<br>Connecting rod/piston pin hole<br>Connecting rod big end<br>Crankshaft R/L side oil seal<br>Starter reduction gear engaging part<br>Countershaft gear engaging part<br>Final gear engaging part<br>Bearing movable part<br>O-ring face<br>Oil seal lip | <ul style="list-style-type: none"> <li>•Genuine KYMCO Engine Oil (SAE15W-40)</li> <li>•API-SG Engine Oil</li> </ul> |
| Starter idle gear<br>Friction spring movable part/shaft movable part<br>Shaft movable grooved part<br>Kick starter spindle movable part                                                                                                                                                                                                                                                                                                                                                      | High-temperature resistant grease                                                                                   |
| A.C. generator connector<br>Transmission case breather tube                                                                                                                                                                                                                                                                                                                                                                                                                                  | Adhesive                                                                                                            |

# 1. GENERAL INFORMATION

**SUPER 8 50**

## FRAME

The following is the lubrication points for the frame.

Use general purpose grease for parts not listed.

Apply clean engine oil or grease to cables and movable parts not specified.



This will avoid abnormal noise and rise the durability of the motorcycle.



# 1. GENERAL INFORMATION

**SUPER 8 50**

## CABLE & HARNESS ROUTING






# 1. GENERAL INFORMATION


SUPER 8 50

## SUPER 8 50 (US Mode)




# 1. GENERAL INFORMATION

**SUPER 8 50**






# 1. GENERAL INFORMATION



# 1. GENERAL INFORMATION

---






# 1. GENERAL INFORMATION

SUPER 8 50 E5

## WIRING DIAGRAM




# 1. GENERAL INFORMATION

**SUPER 8 50**

## TROUBLESHOOTING

### ENGINE WILL NOT START OR IS HARD TO START


#### Possible cause



# 1. GENERAL INFORMATION


**SUPER 8 50**

## ENGINE LACKS POWER




# 1. GENERAL INFORMATION

**SUPER 8 50**



# 1. GENERAL INFORMATION


## POOR PERFORMANCE AT LOW AND IDLE SPEED



# 1. GENERAL INFORMATION

**SUPER 8 50**

## POOR PERFORMANCE AT HIGH SPEED



## POOR HANDLING


|                                         | Possible cause                                                                                                                               |
|-----------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| 1. If steering is heavy                 | ! Steering stem adjusting nut too tight<br>! Damaged steering head bearings                                                                  |
| 2. If either wheel is wobbling          | ! Excessive wheel bearing play<br>! Bent rim<br>! Improper installed wheel hub<br>! Swing arm pivot bearing excessively worn<br>! Bent frame |
| 3. If the motorcycle pulled to one side | ! Faulty the shock absorber<br>! Front and rear wheel not aligned<br>! Bent fork<br>! Bent swing arm<br>! Bent axle                          |

## 2. FRAME COVERS/EXHAUST MUFFLER

SUPER8 50

### SCHEMATIC DRAWING



2







## 2. FRAME COVERS/EXHAUST MUFFLER

SUPER8 50



## 2. FRAME COVERS/EXHAUST MUFFLER

SUPER8 50



## 2. FRAME COVERS/EXHAUST MUFFLER

|                           |     |                               |     |
|---------------------------|-----|-------------------------------|-----|
| SERVICE INFORMATION ..... | 2-1 | EXHAUST MUFFLER REMOVAL ..... | 2-5 |
| FRAME COVERS .....        | 2-2 |                               |     |

### SERVICE INFORMATION

#### GENERAL INSTRUCTIONS

- When removing frame covers, use special care not to pull them by force because the cover joint claws may be damaged.

#### Items Related for Removal

- Handlebar front cover ——— Handlebar rear cover  
Headlight wire connector
- Handlebar rear cover ——— Speedometer cable and instrument light  
wire connectors, etc.
- Frame body cover ——— Met-in box, rear grip, rear turn signal  
lights, floor board
- Floor board ——— Frame body cover  
Battery and wire connectors
- Leg Shield ——— Front cover, floor board

#### TORQUE VALUES

- |                                |              |
|--------------------------------|--------------|
| Exhaust muffler joint lock nut | 1.0~1.4kgf-m |
| Exhaust muffler lock bolt      | 3.0~3.6kgf-m |

## 2. FRAME COVERS/EXHAUST MUFFLER

### HANDLEBAR COVER


#### UPPER/LOWER HANDLEBAR COVER REMOVAL

Remove the two screws and then remove upper handlebar cover.



Screws

Remove the two bolts and then remove front handlebar cover.



bolts

front handlebar cover.

Remove the two screws and then remove lower handlebar cover.



Screws

## 2. FRAME COVERS/EXHAUST MUFFLER

### FRAME COVERS

#### LEFT AND RIGHT SIDE

Remove the four screws attaching the left side or right side skirt


Remove the left side or right side skirt

\* During removal, do not pull the joint claws forcedly to avoid damage.

Left Side Skirt



Screws



Right Side Skirt

#### FRONT CENTER COVER

Remove the two plastic fasteners on the front cover.

Remove the front center cover.

the front cover




plastic fasteners

#### FRONT COVER REMOVAL

Remove the left side or right side skirt(2-2)

Remove the front center cover(2-2).


Remove the two bolts on the front cover.



Bolts

## 2. FRAME COVERS/EXHAUST MUFFLER

Remove the four screws on the front cover.



Screws

Remove the ten screws on the back of the front cover.

Remove the front cover.

The installation sequence is the reverse of removal.



Screws

### **MET-IN BOX REMOVAL**

Open the seat and remove the four bolt attaching the met-in box.

Remove the met-in box .




Bolts


## 2. FRAME COVERS/EXHAUST MUFFLER

### FRAME BODY COVER REMOVAL


Remove the two screws on the battery cover.  
Remove the center cover



Remove the three bolts attaching the rear carrier.  
Remove the rear carrier.




Remove the two bolt attaching the left and right rear step.  
Remove the rear step



Remove the two screws attaching the left side and right side skirt

Remove the left side and right side skirt

**\*** During removal, do not pull the joint claws forcibly to avoid damage.  
When installing, be sure to connect the seat lock wire.






## 2. FRAME COVERS/EXHAUST MUFFLER

Remove the two screws on the center rear cover.


Remove the center rear cover.

.

Center Rear Cover.



Remove the two bolts attaching the frame body cover.




Bolts

Remove the two bolts attaching the rear fender.

Disconnect the taillight wire connector

Remove the rear fender.


Bolts



Rear Fender

Wire

Remove the six screws attaching the fender rear inner.



Screws

## 2. FRAME COVERS/EXHAUST MUFFLER

Disconnect the seat lock wire.

Disconnect the tail lamp wire connectors

Remove the left and right body cover


The installation sequence is the reverse of remove

**\***

During removal, do not pull the joint claws forcibly to avoid damage.  
When installing, be sure to connect the seat lock wire.

Seat Lock Wire

the left body cover



### FLOOR BOARD REMOVAL

Remove the rear carrier. (⇒2-3)


Remove the met-in box. (⇒2-3)

Remove the frame body cover. (⇒2-4)

Remove the four bolts attaching the floor board.

Remove the floor board.

Bolts



Floor Board.

### FRONT FENDER AND UNDER COWL REMOVAL


Remove the two on the under cowl.

Remove the under cowl.

Remove the L/R side bolts attaching the front fender and front fender.

Under Cowl

Screws



Bolt

Front Fender

### LEG SHIELD REMOVAL


Remove the two clip body on the lid leg shield

Remove the lid leg shield.

The installation sequence is the reverse of remove


Clip Body.

Lid Leg Shield.



## 2. FRAME COVERS/EXHAUST MUFFLER

Remove the decorative ring.  
Remove the leg shield.  
The installation sequence is the reverse of remove



### EXHAUST MUFFLER REMOVAL

Disconnect the O<sub>2</sub> Sensor connector.  
Remove the two exhaust muffler joint lock nuts.  
Remove the two exhaust muffler lock bolts.  
Remove the exhaust muffler.  
Remove the exhaust muffler joint packing collar.

When installing, first install the exhaust muffler packing collar and then install the exhaust muffler.  
First install and tighten the exhaust muffler joint lock nuts. Then, install and tighten the exhaust muffler lock bolts.  
Connect the O<sub>2</sub> Sensor connector.


#### Torques:

Exhaust muffler lock bolt: 3.0~3.6kgf-m  
Exhaust muffler joint lock nut: 1.0~1.4kgf-m

\* Be sure to install a new exhaust muffler packing collar.



Bolts



Lock Nut

# 3. INSPECTION/ADJUSTMENT

|                                       |                                          |
|---------------------------------------|------------------------------------------|
| <b>SERVICE INFORMATION.....3-0</b>    | <b>FINAL REDUCTION GEAR OIL.....3- 7</b> |
| <b>MAINTENANCE SCHEDULE .....3-2</b>  | <b>DRIVE BELT.....3- 7</b>               |
| <b>FUEL FILTER.....3-3</b>            | <b>HEADLIGHT AIM .....3- 8</b>           |
| <b>THROTTLE OPERATION .....3-3</b>    | <b>NUTS/BOLTS/FASTENERS .....3- 9</b>    |
| <b>AIR CLEANER .....3-4</b>           | <b>WHEELS/TIRES.....3- 9</b>             |
| <b>SPARK PLUG.....3-4</b>             | <b>STEERING HANDLEBAR.....3- 9</b>       |
| <b>VALVE CLEARANCE.....3-5</b>        |                                          |
| <b>CARBURETOR IDLE SPEED .....3-5</b> |                                          |
| <b>IGNITION TIMING .....3-6</b>       |                                          |
| <b>CYLINDER COMPRESSION .....3-6</b>  |                                          |

## SERVICE INFORMATION

### GENERAL

#### WARNING

- Before running the engine, make sure that the working area is well-ventilated. Never run the engine in a closed area. The exhaust contains poisonous carbon monoxide gas which may cause death to people.
- Gasoline is extremely flammable and is explosive under some conditions. The working area must be well-ventilated and do not smoke or allow flames or sparks near the working area or fuel storage area.

## SPECIFICATIONS

### ENGINE

Throttle grip free play : 2~6mm  
 Spark plug gap : 0.6~0.7mm  
 Spark plug : NGK CR7HSA

Valve clearance : IN: 0.10mm  
 : EX: 0.10mm

Idle speed : 2000rpm

#### Engine oil capacity:

At disassembly : 0.85 liter

At change : 0.7 liter

#### Gear oil capacity :

At disassembly : 0.21 liter

At change : 0.18 liter

**3**

### 3. INSPECTION/ADJUSTMENT

---

Cylinder compression : 12kg/cm<sup>2</sup>

Ignition timing: 13° ~ 28°

#### CHASSIS

Front brake free play : 10~20mm

Rear brake free play : 10~20mm

#### TIRE PRESSURE

|       | 1 Rider                | 2 Riders               |
|-------|------------------------|------------------------|
| Front | 1.5kg/cm <sup>2</sup>  | 2.0kg/cm <sup>2</sup>  |
| Rear  | 1.75kg/cm <sup>2</sup> | 2.25kg/cm <sup>2</sup> |

#### TIRE SIZE:

Front : 120/70-14

Rear : 120/80-14

#### TORQUE VALUES

Front axle nut 5.0~7.0kgf-m

Rear axle nut 11~13kgf-m

### 3. INSPECTION/ADJUSTMENT

#### MAINTENANCE SCHEDULE

Perform the periodic maintenance at each scheduled maintenance period.

I: Inspect, and Clean, Adjust, Lubricate or Replace if necessary.

A: Adjust C: Clean R: Replace T : Tighten

| Item                     | Frequency | Whichever comes first ⇔<br>↓                   | Regular Service Mileage (km) |      |      |      |      |      |      |      |      |       |       |       |
|--------------------------|-----------|------------------------------------------------|------------------------------|------|------|------|------|------|------|------|------|-------|-------|-------|
|                          |           |                                                | 1000                         | 2000 | 3000 | 4000 | 5000 | 6000 | 7000 | 8000 | 9000 | 10000 | 11000 | 12000 |
| Engine oil               |           | R New Motorcycle 300km                         | R                            |      |      | R    |      |      | R    |      | R    |       | R     |       |
| Engine oil filter screen |           |                                                |                              |      |      | C    |      |      |      | C    |      |       |       |       |
| Fuel filter screen       |           |                                                |                              |      |      |      |      |      |      |      |      | R     |       |       |
| Gear oil                 | Note 3    | R New motorcycle 300km                         |                              |      |      |      | R    |      |      |      |      | R     |       |       |
| Valve clearance          |           |                                                |                              | A    |      | A    |      |      |      | A    |      |       |       | A     |
| Air Cleaner              | Note 2,3  | Replace at every 2000km                        |                              |      |      |      |      |      |      |      |      |       |       |       |
| Spark plug               |           | Clean at every 3000km and replace if necessary |                              |      |      |      |      |      |      |      |      |       |       |       |
| Brake system             |           |                                                | I                            | I    | I    | I    | I    | I    | I    | I    | I    | I     | I     | I     |
| Drive belt               |           |                                                |                              |      |      |      |      |      |      | I    |      |       |       |       |
| Suspension               |           |                                                |                              |      |      | I    |      |      |      | I    |      |       |       | I     |
| Nut, bolt, fastener      |           |                                                |                              |      |      |      |      |      |      | I    |      |       |       |       |
| Tire                     |           |                                                |                              |      |      | I    |      |      |      | I    |      |       |       | I     |
| Steering head bearing    |           |                                                | I                            |      |      |      |      | I    |      |      |      |       |       | I     |

- In the interest of safety, we recommend these items should be serviced only by an authorized KYMCO motorcycle dealer.

Note: 1. For higher odometer readings, repeat at the frequency interval established here.

2. Service more frequently when riding in dusty or rainy areas.

3. Service more frequently when riding in rain or at full throttle.

### 3. INSPECTION/ADJUSTMENT


#### THROTTLE OPERATION

Check the throttle grip for smooth movement.  
Measure the throttle grip free play.


**Free Play:** 2~6mm



Major adjustment of the throttle grip free play is made at the carburetor side.  
Adjust by loosening the lock nut and turning the adjusting nut.



Minor adjustment is made with the adjusting nut at the throttle grip side.  
Slide the rubber cover out and adjust by loosening the lock nut and turning the adjusting nut.





### 3. INSPECTION/ADJUSTMENT

Super 8 50

#### AIR CLEANER

##### AIR CLEANER REPLACEMENT

Remove the air cleaner case cover by removing the 7 screws.

Remove the air cleaner element by removing the four screws.

Check the element and replace it if it is excessively dirty or damaged.

##### CHANGE INTERVAL

More frequent replacement is required when riding in unusually dusty or rainy areas.


- \* The air cleaner element has a viscous type paper element. Do not clean it with any fluid.
- Be sure to install the air cleaner element and cover securely.

Air Cleaner Case Cover



Screws

Air Cleaner Element



#### SPARK PLUG


Remove the spark plug.

Check the spark plug for wear and fouling deposits.

Clean any fouling deposits with a spark plug cleaner or a wire brush.

##### Specified Spark Plug:


NGK CR7HSA



Measure the spark plug gap.

**Spark Plug Gap:** 0.6~0.7mm

- \* When installing, first screw in the spark plug by hand and then tighten it with a spark plug wrench.




### 3. INSPECTION/ADJUSTMENT

#### VALVE CLEARANCE

- \* Inspect and adjust valve clearance while the engine is cold (below 35°C).


Remove the frame cover. (⇒2-3)  
 Remove the six bolts on the cylinder head cover.  
 Remove the cylinder head cover. (⇒7-3)  
 Remove the cylinder head cover..

Cylinder Head Cover



Bolts

Turn the flywheel counterclockwise so that the "T" mark on the flywheel aligns with the index mark on the crankcase to bring the round hole on the camshaft gear facing up to the top dead center on the compression stroke.



Round Hole

Inspect and adjust the valve clearance.

**Valve Clearance:** IN : 0.1mm  
 EX: 0.1mm


Loosen the lock nut and adjust by turning the adjusting nut

**Special**

Tappet Adjuster

- \* • Check the valve clearance again after the lock nut is tightened.

Tappet Adjuster



Feeler Gauge

### 3. INSPECTION/ADJUSTMENT

Super 8 50

#### IGNITION TIMING

\* The CDI unit is not adjustable. If the ignition timing is incorrect, check the ignition system. (⇒15-5)

Remove the right of the fan cover.

Timing Hole Cap



Check the ignition timing with a timing light. When the engine is running at idle speed, the ignition timing is correct if the "F" mark on the flywheel aligns with the index mark on the crankcase.

Timing Light



Also use a timing light to check the advance. Raise the engine speed to 4,000rpm and the index mark on the crankcase cover should be aligned with the advance mark on the flywheel.


#### CYLINDER COMPRESSION

Warm up the engine before compression test. Remove the met-in box and center cover. (⇒2-3)


Remove the spark plug.

Insert a compression gauge.

Open the throttle valve fully and push the starter button to test the compression.



Compression Gauge



**Compression:** 13kg/cm<sup>2</sup>rpm

If the compression is low, check for the following:

- Leaky valves
- Valve clearance too small
- Leaking cylinder head gasket
- Worn piston rings
- Worn piston/cylinder

If the compression is high, it indicates that carbon deposits have accumulated on the combustion chamber and the piston head.

### 3. INSPECTION/ADJUSTMENT

#### FINAL REDUCTION GEAR OIL OIL LEVEL CHECK

- \* Place the motorcycle on its main stand on level ground for oil level check.


Stop the engine and remove the oil check bolt. The oil level shall be at the oil check bolt hole.

If the oil level is low, add the recommended oil to the proper level.


**Recommended Oil: SAE90#**

Install the oil check bolt.

- \* Make sure that the sealing washer is in good condition.



Oil Check Bolt/Sealing Washer



Oil Check Bolt Hole

#### OIL CHANGE

Remove the oil check bolt.

Remove the oil drain bolt and drain the oil thoroughly.

Install the oil drain bolt.

**Torque: 0.8~1.2kgf-m**

- \* Make sure that the sealing washer is in good condition.

Fill with the recommended oil.

**Oil Capacity:** At disassembly : 0.21liter  
At change : 0.18 liter

Reinstall the oil check bolt and check for oil leaks.

**Torque: 0.8~1.2kgf-m**




Oil Drain Bolt/ Sealing Washer

#### DRIVE BELT

Remove the left crankcase cover. (⇒9-2)

Inspect the drive belt for cracks or excessive wear.

Replace the drive belt with a new one if necessary and in accordance with the Maintenance Schedule.



Drive Belt

### 3. INSPECTION/ADJUSTMENT

Super 8 50

#### HEADLIGHT AIM

Turn the ignition switch ON and start the engine.

Turn on the headlight switch.


Adjust the headlight aim by turning the headlight aim adjusting screw.



#### CLUTCH SHOE WEAR

Start the engine and check the clutch operation by increasing the engine speed gradually.

If the motorcycle tends to creep, or the engine stalls, check the clutch shoes for wear and replace if necessary. (⇒9-11)



clutch

#### SUSPENSION

##### FRONT

Fully apply the front brake lever and check the action of the front shock absorbers by compressing them several times.

Check the entire shock absorber assembly for oil leaks, looseness or damage.



##### REAR

Check the action of the rear shock absorber by compressing it several times.

Check the entire shock absorber assembly for oil leaks, looseness or damage.

Jack the rear wheel off the ground and move the rear wheel sideways with force to see if the engine hanger bushings are worn.

### 3. INSPECTION/ADJUSTMENT

#### NUTS/BOLTS/FASTENERS

Check all important chassis nuts and bolts for looseness.

Tighten them to their specified torque values if any looseness is found. (⇒1-11)

#### WHEELS/TIRES

Check the tires for cuts, imbedded nails or other damages.

Check the tire pressure.

\* Tire pressure should be checked when tires are cold.

#### TIRE PRESSURE

|       | 1 Rider                | 2 Riders               |
|-------|------------------------|------------------------|
| Front | 1.5kg/cm <sup>2</sup>  | 1.75kg/cm <sup>2</sup> |
| Rear  | 2.00kg/cm <sup>2</sup> | 2.25kg/cm <sup>2</sup> |

#### TIRE SIZE

**Front** : 120/70-14

**Rear** : 120/80-14

Check the front axle nut for looseness.

Check the rear axle nut for looseness.

If the axle nuts are loose, tighten them to the specified torques.

**Torques: Front** : 5.0~7.0kgf-m

**Rear** : 11~13kgf-m

#### STEERING HANDLEBAR

Check that the control cables do not interfere with handlebar rotation.

Raise the front wheel off the ground and check that the steering handlebar rotates freely.

If the handlebar moves unevenly, binds, or has vertical movement, adjust the steering head bearing.




Front Axle



## 4. LUBRICATION SYSTEM

### LUBRICATION SYSTEM



4

## 4. LUBRICATION SYSTEM

|                          |     |                            |     |
|--------------------------|-----|----------------------------|-----|
| SERVICE INFORMATION..... | 4-1 | ENGINE OIL/OIL FILTER..... | 4-2 |
| TROUBLESHOOTING.....     | 4-1 | OIL PUMP .....             | 4-3 |

### SERVICE INFORMATION

#### GENERAL INSTRUCTIONS

- The maintenance of lubrication system can be performed with the engine installed in the frame.
- Use care when removing and installing the oil pump not to allow dust and foreign matters to enter the engine and oil line.
- Do not attempt to disassemble the oil pump. The oil pump must be replaced as a set when it reaches its service limit.
- After the oil pump is installed, check each part for oil leaks.

#### SPECIFICATIONS

| Item     |                                      | Standard (mm) | Service Limit (mm) |
|----------|--------------------------------------|---------------|--------------------|
| Oil pump | Inner rotor-to-outer rotor clearance | —             | 0.12               |
|          | Outer rotor-to-pump body clearance   | —             | 0.12               |
|          | Rotor end-to-pump body clearance     | 0.05~0.10     | 0.2                |

### TROUBLESHOOTING

#### Oil level too low

- Natural oil consumption
- Oil leaks
- Worn or poorly installed piston rings
- Worn valve guide or seal

#### Poor lubrication pressure

- Oil level too low
- Clogged oil filter or oil passages
- Not use the specified oil




## 4. LUBRICATION SYSTEM

### ENGINE OIL/OIL FILTER

#### OIL LEVEL

- \* Place the motorcycle upright on level ground for engine oil level check.
- \* Run the engine for 2~3 minutes and check the oil level after the engine is stopped for 2~3 minutes.

Remove the oil dipstick and check the oil level with the oil dipstick.  
If the level is near the lower level, fill to the upper level with the specified engine oil.



Oil Dipstick

#### OIL CHANGE

- \* The engine oil will drain more easily while the engine is warm.


Remove the drain bolt to drain the engine oil thoroughly.  
Remove the oil filter screen cap and clean the oil filter screen with compressed air.



Oil Filter Screen Cap

Check the filter screen O-ring for damage and replace if necessary.  
Install the oil filter screen, spring and filter screen cap.

**Torque:** 1.0~2.0kgf-m



O-ring

Fill the crankcase with the specified engine oil to the proper level.

Oil Capacity: At disassembly : 0.85 liter  
At change : 0.70 liter

Check for oil leaks and then start the engine and let it idle for few minutes.  
Recheck the oil level.

## 4. LUBRICATION SYSTEM


### OIL PUMP

#### REMOVAL

Remove the A.C. generator flywheel. (⇒14-7)

Remove the A.C. generator stator and pulsar coil. (⇒14-6)

Remove the eight right crankcase cover bolts and the right crankcase cover.



Bolts

Remove the gasket and dowel pins.

Remove the oil pump drive gear circlip.

Remove the oil pump gear.

Right Crankcase Cover




Oil Pump Drive Gear

Circlip

Remove the oil pump mounting bolts.

Remove the oil pump.




Oil Pump Gear

Oil Pump

Remove the two O-rings.

Inspect the two O-rings for damage or deterioration.



Bolts


O-rings

## 4. LUBRICATION SYSTEM

### DISASSEMBLY

Remove the three oil pump boby screws.  
Disassembly the oil pump.

Oil Pump Bobby



Screws

Outer Rotor



### INSPECTION

Measure the pump boby-to-outer rotor clearance.


**Service Limit:** 0.12mm

Measure the inner rotor-to-outer rotor clearance.

**Service Limit:** 0.12mm

Oil Pump Bobby


Outer Rotor



Measure the rotor end-to- pump boby clearance.

**Service Limit:** 0.2mm

Inner Rotor




## 4. LUBRICATION SYSTEM

### ASSEMBLY


Install the outer rotor, inner rotor and pump shaft into the pump body.

- \* Install the pump shaft by aligning the flat on the shaft with the flat in the inner rotor.



Pump Shaft


Install the pump cover and tighten the screws to secure the pump cover.



Pump Cover

### INSTALLATION

First install the two O-rings onto the oil pump base.




O-rings

Install the oil pump into the crankcase.

- \* Fill the oil pump with engine oil before installation.

After the oil pump is installed, tighten the three mounting bolts.




Bolts

## 4. LUBRICATION SYSTEM

Install the pump driven gear and secure it with the circlip.

**Torque:** 0.8~1.2kg-m

Pump Driven Gear




Circlip

Install the right crankcase cover and tighten the eight bolts.

**Torque:** 0.8~1.2kgf-m

\* Diagonally tighten the bolts in 2~3 times.

Right Crankcase Cover



Bolts

## **5. FUEL INJECTION SYSTEM**

---

### **FUEL INJECTION SYSTEM**


**5**

|                                   |       |
|-----------------------------------|-------|
| SYSTEM DIAGRAM .....              | 5 - 1 |
| SYSTEM LOCATION.....              | 5 - 2 |
| SERVICE INFORMATION .....         | 5 - 3 |
| TROUBLESHOOTING .....             | 5 - 4 |
| CHECK ENGINE LAMP (CELP).....     | 5 - 5 |
| HOW TO SHOW THE FAILURE CODE..... | 5 - 6 |
| FAILURE CODES CHART .....         | 5 - 7 |
| ECU .....                         | 5-11  |
| FUEL PUMP .....                   | 5-12  |
| T-MAP & TPS.....                  | 5-13  |
| ETS .....                         | 5-14  |
| INJECTOR .....                    | 5-14  |
| O <sub>2</sub> SENSOR.....        | 5-15  |

## 5. FUEL INJECTION SYSTEM

SUPER 8 50

### SYSTEM DIAGRAM









## 5. FUEL INJECTION SYSTEM

### Parts Location

- |                            |                    |
|----------------------------|--------------------|
| 01:Inductive ignition coil | 06:T-MAP sensor    |
| 02:Fuel pump               | 07:ABV             |
| 03:ECU                     | 08:TPS             |
| 04:Fuel injector           | 09:CPS             |
| 05:ETS sensor              | 10:O2/O2 HT sensor |





## 5. FUEL INJECTION SYSTEM

**SUPER 8 50**

### SERVICE INFORMATION

#### GENERAL INSTRUCTIONS

**\***

Gasoline is very dangerous. When working with gasoline, keep sparks and flames away from the working area.  
Gasoline is extremely flammable and is explosive under certain conditions. Be sure to work in a well-ventilated area.

- Disconnect the cables of the battery when the engine is running, which could lead to ECU damage.
- Connect the harness positive (+) cable to the battery negative (-) terminal or connect the harness negative (-) to the battery positive (+) terminal, which could lead to ECU damage.
- Always keep fuel over 750 cc in fuel tank.

#### SPECIFICATIONS

| Item                                           |                             |                      | Standard                                                    |
|------------------------------------------------|-----------------------------|----------------------|-------------------------------------------------------------|
| Charging voltage of battery                    |                             |                      | 13.5 ~ 14.5V                                                |
| Voltage from the ECU to sensor                 |                             |                      | 5 ±0.1V                                                     |
| Fuel injector resistance (20 ℃/68 ℉)           |                             |                      | 10.6 ~ 15.9Ω                                                |
| Temperature sensor resistance                  |                             |                      | 10--12 KΩ (25 ℃)                                            |
| Throttle position sensor voltage               |                             |                      | Idle (0 °) = 0.23±0.05V<br>Throttle fully (90 °/3.27V over) |
| Fuel pump resistance (20 ℃/68 ℉)               |                             |                      | about 2Ω                                                    |
| O2 sensor                                      | O2 sensor heater resistance |                      | 6.7 ~ 9.5Ω                                                  |
|                                                | Voltage                     | Air/Fuel<14.7 (Rich) | >0.7V                                                       |
|                                                |                             | Air/Fuel>14.7 (Lean) | <0.18V                                                      |
| Crank position sensor (Pulser) resistance      |                             |                      | 95 ~ 144Ω                                                   |
| Inductive ignition coil resistance (20 ℃/68 ℉) |                             |                      | 0.55 ~ 0.75Ω                                                |
| Roll sensor voltage (diagnostics)              |                             |                      | Normal: 0.3 ~ 1.4V<br>Fall down ( >65 °): 3.5 ~ 4.7V        |
| Idle speed                                     |                             |                      | 2000 ±100 rpm                                               |

**TROUBLESHOOTING****Engine won't start**

- Battery voltage too low
- Fuel level too low
- Pinched or clogged fuel hose
- Faulty fuel pump operating system
- Clogged fuel filter (fuel pump)
- Clogged fuel injector
- Faulty spark plug or wrong type
- Cut by ECU due to angle detect sensor or incorrect function

**Backfiring or misfiring during acceleration**

- Ignition system malfunction

**Poor performance (drive ability) and poor fuel economy**

- Pinched or clogged fuel hose
- Faulty fuel injector

**Engine stall, hard to start, rough idling**


- Intake air leak
- Fuel contaminated/deteriorated
- Pinched or clogged fuel hose
- Idle speed misadjusted

## 5. FUEL INJECTION SYSTEM

SUPER 8 50

### CHECK ENGINE LAMP (CEL P)

1. When turning on the switch, the CLEP indicator will illuminate always. it goes off after start the engine.
2. If there is any malfunction, the CLEP indicator will still illuminate,
3. please take your scooter to a KYMCO dealer for service as soon as possible.



## 5. FUEL INJECTION SYSTEM

SUPER 8 50

### Failure Code Chart

| No | Diagnose code | Failure Code | Pcode                                                                  | NOTE |
|----|---------------|--------------|------------------------------------------------------------------------|------|
| 1  | D1            | B0099        | B0099 Roll sensor Voltage High                                         |      |
| 2  | F0            | C0064        | C0064 Roll sensor malfunction                                          |      |
| 3  | A1            | P0030        | P0030 O2 sensor heater malfunction                                     |      |
| 4  | A2            | P0031        | P0031 O2 sensor heater Voltage Low                                     |      |
| 5  | A3            | P0032        | P0032 Lambda sensor heater Voltage High                                |      |
| 6  | A4            | P0105        | P0105 MAP sensor malfunction                                           |      |
| 7  | A5            | P0107        | P0107 MAP sensor Voltage Low                                           |      |
| 8  | A6            | P0108        | P0108 MAP sensor Voltage High                                          |      |
| 9  | A7            | P0110        | P0110 Intake air temperature sensor malfunction or Voltage High        |      |
| 10 | A8            | P0111        | P0111 Intake air temperature circuit malfunction                       |      |
| 11 | A9            | P0112        | P0112 Intake air temperature sensor Voltage Low                        |      |
| 12 | D6            | P0113        | P0113 Intake air temperature sensor Voltage High                       |      |
| 13 | AA            | P0114        | P0114 Intake air temperature intermittent failure                      |      |
| 14 | AB            | P0115        | P0115 Engine Temperature Sensor malfunction or Voltage High            |      |
| 15 | AC            | P0117        | P0117 Engine Temperature Sensor Voltage Low                            |      |
| 16 | AD            | P0118        | P0118 Engine Temperature Sensor Voltage High                           |      |
| 17 | AE            | P0119        | P0119 Engine Temperature intermittent failure                          |      |
| 18 | AF            | P0120        | P0120 Throttle Position Sensor malfunction or Voltage Low              |      |
| 19 | B0            | P0121        | P0121 Throttle position sensor adaptation is out of range              |      |
| 20 | B1            | P0122        | P0122 Throttle Position Sensor Voltage Low                             |      |
| 21 | B2            | P0123        | P0123 Throttle Position Sensor Voltage High                            |      |
| 22 | B3            | P0124        | P0124 Difference between the two last TPS acquisitions is out of range |      |
| 23 | B4            | P0130        | P0130 O2 sensor signal malfunction                                     |      |
| 24 | B5            | P0131        | P0131 O2 sensor signal Voltage Low                                     |      |
| 25 | B6            | P0132        | P0132 O2 sensor signal Voltage High                                    |      |
| 26 | D7            | P0171        | P0171 System over lean or over rich (Too Lean)                         |      |
| 27 | D8            | P0172        | P0172 System over lean or over rich (Too Rich)                         |      |
| 28 | B7            | P0200        | P0200 Injection malfunction                                            |      |
| 29 | DA            | P0201        | P0201 Injection valve malfunction                                      |      |
| 30 | B8            | P0217        | P0217 Engine over temperature condition                                |      |
| 31 | B9            | P0219        | P0219 CVT overspeed detected                                           |      |
| 32 | BA            | P0230        | P0230 Fuel pump malfunction                                            |      |
| 33 | BB            | P0231        | P0231 Fuel pump Voltage Low                                            |      |
| 34 | BC            | P0232        | P0232 Fuel pump Voltage High                                           |      |
| 35 | BD            | P0260        | P0260 Injection valve malfunction                                      |      |
| 36 | BE            | P0261        | P0261 Injection valve Voltage Low                                      |      |

## 5. FUEL INJECTION SYSTEM

**SUPER 8 50**

|    |    |       |                                                   |  |
|----|----|-------|---------------------------------------------------|--|
| 37 | BF | P0262 | P0262 Injection valve Voltage High                |  |
| 38 | BE | P0264 | P0264 Injection valve Voltage Low                 |  |
| 39 | BF | P0265 | P0265 Injection valve Voltage High                |  |
| 40 | C0 | P0335 | P0335 Crankshaft sensor malfunction               |  |
| 41 | C1 | P0350 | P0350 Ignition malfunction or Voltage Low         |  |
| 42 | C2 | P0351 | P0351 Ignition Voltage High                       |  |
| 43 | DB | P0412 | P0412 Secondary air injection system malfunction  |  |
| 44 | C3 | P0480 | P0480 Fan Relay/Circuit malfunction               |  |
| 45 | F1 | P0484 | P0484 Fan Relay/Circuit Voltage High              |  |
| 46 | F2 | P0485 | P0485 Fan Relay/Circuit Voltage Low               |  |
| 47 | DE | P0500 | P0500 Vehicle Speed Sensor malfunction            |  |
| 48 | D9 | P0501 | P0501 Vehicle Speed Sensor malfunction            |  |
| 49 | C4 | P0505 | P0505 ISAV idle speed actuator valve malfunction  |  |
| 50 | C5 | P0508 | P0508 ISAV idle speed actuator valve Voltage Low  |  |
| 51 | C6 | P0509 | P0509 ISAV idle speed actuator valve Voltage High |  |
| 52 | DF | P0511 | P0511 ISC stepper motor malfunction               |  |
| 53 | F3 | P0560 | P0560 Battery voltage VBK malfunction             |  |
| 54 | F4 | P0561 | P0561 Battery voltage VBK malfunction             |  |
| 55 | C7 | P0562 | P0562 Battery voltage VBK too Low                 |  |
| 56 | C8 | P0563 | P0563 Battery voltage VBK too High                |  |
| 57 | DC | P0603 | P0603 ECU memory error                            |  |
| 58 | F7 | P0615 | P0615 Starter Relay malfunction                   |  |
| 59 | F8 | P0616 | P0616 Starter Relay Voltage Low                   |  |
| 60 | F9 | P0617 | P0617 Starter Relay Voltage High                  |  |
| 61 | C9 | P0650 | P0650 MIL Voltage High                            |  |
| 62 | CA | P0700 | P0700 Engine overspeed detected                   |  |
| 63 | CB | P1110 | P1110 Roll sensor Voltage High                    |  |
| 64 | CC | P1111 | P1111 Roll sensor malfunction or Voltage Low      |  |
| 65 | DD | P1205 | P1205 MAP sensor malfunction                      |  |
| 66 | CD | P1410 | P1410 AISV system break down                      |  |
| 67 | E0 | P1505 | P1505 ISC system malfunction                      |  |
| 68 | E1 | P1521 | P1521 VACS Valve circuit malfunction              |  |
| 69 | CE | P1630 | P1630 Roll sensor circuit malfunction             |  |
| 70 | CF | P2187 | P2187 Lambda control too High                     |  |
| 71 | D0 | P2188 | P2188 Lambda control too Low                      |  |
| 72 | D4 | P2300 | P2300 Ignition malfunction or Voltage Low         |  |
| 73 | D5 | P2301 | P2301 Ignition malfunction or Voltage High        |  |
| 74 | D4 | P2303 | P2303 Ignition malfunction or Voltage Low         |  |
| 75 | D5 | P2304 | P2304 Ignition malfunction or Voltage High        |  |
| 76 | D3 | P263A | P263A MIL Voltage Low                             |  |

## 5. FUEL INJECTION SYSTEM

**SUPER 8 50**

|     |    |       |                                                                                              |  |
|-----|----|-------|----------------------------------------------------------------------------------------------|--|
| 77  | D2 | P263B | P263B MIL Voltage High                                                                       |  |
| 78  |    | C006A | C006A Accelerometer identifier diagnosis Failure of self test                                |  |
| 79  |    | P0106 | P0106 Stuck MAP signal                                                                       |  |
| 80  |    | P0116 | P0116 TCO out of range                                                                       |  |
| 81  |    | P0133 | P0133 Oxygen sensor switching time monitoring Implausible oxygen sensor switching time       |  |
| 82  |    | P0134 | P0134 Lambda sensor diagnosis Open signal                                                    |  |
| 83  |    | P0135 | P0135 Lambda sensor heater plausibility diagnosis Lambda sensor heater implausible operation |  |
| 84  |    | P016B | P016B Lambda controller Excessive positive deviation of lambda controller                    |  |
| 85  |    | P016C | P016C Lambda controller Excessive negative deviation of lambda controller                    |  |
| 86  |    | P0300 | P0300 Multiple misfire A diagnosis                                                           |  |
| 87  |    | P0313 | P0313 Misfire fuel tank low                                                                  |  |
| 88  |    | P0314 | P0314 Misfire A diagnosis                                                                    |  |
| 89  |    | P0336 | P0336 Crankshaft wrong tooth number diagnosis Additional CRK tooth detected                  |  |
| 90  |    | P0339 | P0339 Crankshaft sensor Additional edges inside filtering period                             |  |
| 91  |    | P0410 | P0410 Secondary Air Valve Plausibility diagnosis Secondary Air Valve Unplausible             |  |
| 92  |    | P0413 | P0413 Secondary air valve diagnosis Open signal                                              |  |
| 93  |    | P0414 | P0414 Secondary air valve diagnosis Signal shorted to ground                                 |  |
| 94  |    | P0444 | P0444 Canister purge solenoid diagnosis Open signal                                          |  |
| 95  |    | P0458 | P0458 Canister purge solenoid diagnosis Signal shorted to ground                             |  |
| 96  |    | P0459 | P0459 Canister purge solenoid diagnosis Signal shorted to battery                            |  |
| 97  |    | P0503 | P0503 Intermittent vehicle speed signal from CAN diagnosis                                   |  |
| 98  |    | P0519 | P0519 Stepper plausibility diagnosis Implausible stepper control                             |  |
| 99  |    | P0661 | P0661 Variable intake pipe diagnosis Signal shorted to battery                               |  |
| 100 |    | P0662 | P0662 Variable intake pipe diagnosis Signal shorted to ground                                |  |
| 101 |    | P0663 | P0663 Variable intake pipe diagnosis Signal open                                             |  |
| 102 |    | P0894 | P0894 CVT overspeed Transmission component slipping                                          |  |
| 103 |    | P2A00 | P2A00 Oxygen sensor out of range                                                             |  |
| 104 |    | U0241 | U0241 Head lamp diagnosis Signal shorted to ground                                           |  |
| 105 |    | U1601 | U1601 CAN Bus off diagnosis Bus off                                                          |  |
| 106 |    | U1605 | U1605 CAN control unit diagnosis for checked received messages Fail                          |  |
| 107 |    | P0643 | P0643 Reference voltage diagnosis 1 Signal shorted to battery                                |  |
| 108 |    | P0608 | P0608 Reference voltage diagnosis 1 Signal shorted to ground or open                         |  |

5. FUEL INJECTION SYSTEM


SUPER 8 50

ECU

There are 34 pins attaching the ECU.



ECU PIN FUNCTION



|     |       |              |  |     |       |               |  |
|-----|-------|--------------|--|-----|-------|---------------|--|
| 09  | W/R   | INJECTION    |  | 18  | G/BR  | PUMP RELAY    |  |
| 08  | W/Y   | K-LINE       |  | 17  |       |               |  |
| 07  | B     | VBK          |  | 16  |       | VEH SPEED     |  |
| 06  |       | TILT         |  | 15  | G/L   | ECT           |  |
| 05  | W3    | HEGO HEAT    |  | 14  | R/Y   | VBD           |  |
| 04  | G/W   | CPS(-)       |  | 13  | L/Y   | CPS(+)        |  |
| 03  |       |              |  | 12  | B2    | HEGO SENS     |  |
| 02  |       | RPM/TEMP OUT |  | 11  | L/R   | MIL           |  |
| 01  | V/G   | PGND         |  | 10  | B/Y   | IGNITION COIL |  |
| PIN | COLOR | PI FUNCTION  |  | PIN | COLOR | PI FUNCTION   |  |

MAP content (edition issue no.)

ECU




## **5. FUEL INJECTION SYSTEM**

### **FUEL PUMP**

Connect the meter (+) probe to the red/black wire and the meter (-) probe to the green wire to measure the voltage from the ECU input to fuel pump unit.

Standard : 8~16 V (Battery volt)

To measure the resistance of the fuel pump to see if it is short circuit or not.





## 5. FUEL INJECTION SYSTEM

SUPER 8 50

### T-MAP(Manifold Air Temperature Pressure) Sensor


Connect the PDA or Fi diagnostic tool.

Enter the Data Analyze

Check if the manifold pressure data is malfunction.


Turn the ignition switch to the “ON” position.

If data is incorrect, and the T-map sensor is problem.



**Standard : 101.3  $\pm$ 3 kpa on sea altitude**

The ambient pressure drop is about **12Kpa** according to the altitude raises.




### TPS (Throttle Position Sensor)

Enter the Data Analyze

Check if the TPS position data is malfunction.

Turn the ignition switch to the “ON” position.


If data is incorrect even the Idle and throttle fully, the TPS is problem.



**Standard :**

Idle ~0 ° 0.23V  $\pm$ 0.05

Throttle fully ~90 ° > 3.27V



## **5. FUEL INJECTION SYSTEM**

### **ETS (Engine Temperature Sensor)**

Connect the meter (+) probe to the V/G wire and the meter (-) probe to the G/L wire to measure the voltage

**Standard :  $5 \pm 0.25$  V**

Measure the resistance of the WTS


**Standard (25 °C ) : 10--12k $\Omega$**



### **INJECTOR**

Measure the resistance of the Injector

**Standard (20°C/68°F ) : 10.6~15.9 $\Omega$**



## 5. FUEL INJECTION SYSTEM

**SUPER 8 50**



### O2 SENSOR

Measure the resistance of the O2 sensor heater.  
(2 white wire pin)

**Standard (20 °C/68 °F): 6.7 ~9.5Ω**



Connect the PDA or KYMCO Fi diagnostic tool.  
Enter the Data Analyze  
Check Page 05  
Turn the ignition switch to the “ON” position.  
Starting engine till the O2 heater activation is ON.  
If data is incorrect, the O2 sensor is problem.




# Fi Diagnostic Tool Operation Instructions Part No. 3620A-LEB2-E00



- |                                 |                                       |
|---------------------------------|---------------------------------------|
| 1 Model No.                     | 6 UP Button                           |
| 2 Down Button                   | 7 Adjust (TPI and ABV reset function) |
| 3 DTC indicator (Failure codes) | 8 DATA Analyze                        |
| 4 Enter or Exit                 | 9 DTC Inspect                         |
| 5 Power indicator               | 10 ECU Version                        |

### Note: For EURO 5 models

Use the Sub cord, OBD diagnostics, connector (part number:36205-LFA7- E00) to connect between vehicle and diagnostic tool.






## 5. FUEL INJECTION SYSTEM

### DTC INSPECTION

Connect Fi diagnostic tool with the connector of harness wire located beside the Battery.



Press the "Enter" button




Check the software version

Press the "Enter" button and then turn to the first page.




Press the "Down" button to enter the DTC Inspect.




## 5. FUEL INJECTION SYSTEM


Press the "Enter" button to check the DTC number



Press the "Enter" button



Press the "Enter" button




Display the DTC number of the DTC-List. Refer to DTC summary list.

Press the "Enter" button and then turn to the previous page




## 5. FUEL INJECTION SYSTEM


Press the "UP" button




Press the "Enter" button and then turn to the previous page.



Press the "UP" button




Press the "Enter" button and then turn to the first page.




### DTC CLEAR PROCEDURE

Choose "Load DTC"

Press the "Down" button




Press the "Enter" button



The DTC indicator is lighting at that time.



Clearing DTC until the DTC indicator is off.






### DATA ANALYSIS

Choose "Data Analyze"


Press the "Enter" button to enter page 01.



The figure includes the engine speed, idle speed and the battery voltage.

Refer to standard specification.


Press the "Down" button to enter page 02.



The figure includes TPS position, TPI idle adapted voltage and TPI WOT adapted (Throttle grip fully opened).

Refer to standard specification.

Press the "Down" button to enter page 03.



The figure includes engine working temperature, atmosphere pressure and Manifold pressure.


Refer to standard specifications on page 18-9.

Press the "Down" button to enter page 04.



## 5. FUEL INJECTION SYSTEM


The figure includes fuel injector interval, ignition advance angle and ABV angle. Refer to standard specification. Press the "Down" button to enter page 05.




The figure includes O2 sensor voltage, O2 heater working condition and O2 correction.

Refer to standard specification.

Press the "Down" button to enter page 06.



Press the "Down" button to enter page 07.



The figure includes ECU counter hours.

Press the "UP" button to the first page.

## 5. FUEL INJECTION SYSTEM

| Reason of repair: <input type="checkbox"/> Maintenance <input type="checkbox"/> Breakdown |                                       |                |                               |                                                                                                                    |
|-------------------------------------------------------------------------------------------|---------------------------------------|----------------|-------------------------------|--------------------------------------------------------------------------------------------------------------------|
| Item                                                                                      |                                       | Data           | Reference                     | Memo                                                                                                               |
| ECU Version                                                                               | ECU No                                |                |                               |                                                                                                                    |
|                                                                                           | Hardware Ver                          |                |                               |                                                                                                                    |
|                                                                                           | Software Ver                          |                | QK0A50                        |                                                                                                                    |
|                                                                                           | Calibration Ver                       |                | E5BLA2EUAA                    |                                                                                                                    |
|                                                                                           | Model Name                            |                | BLA2                          |                                                                                                                    |
| DTC                                                                                       | Active                                |                |                               |                                                                                                                    |
|                                                                                           | Occurred                              |                |                               |                                                                                                                    |
|                                                                                           | History                               |                |                               |                                                                                                                    |
| (Cool Engine) Engine Stop                                                                 | Air Temp.(°C)                         |                | environ.temp ± 2 °C           |                                                                                                                    |
|                                                                                           | Engine Temp.(Cooling)                 |                | environ.temp ± 2 °C           |                                                                                                                    |
|                                                                                           | Atom. Pressure (Kpa.)                 |                | 101.3 ± 3 kPa                 | The ambient pressure drop about 12kpa at the altitude every 1000m raised                                           |
|                                                                                           | Throttle Position (%)                 |                | Below2.5° / over90°           |                                                                                                                    |
|                                                                                           | Throttle Position (V)                 |                | 0.23V ± 0.05 / >3.27          | IDLE/Throttle fully                                                                                                |
|                                                                                           | TPI Idle Mean (V)                     |                | 0.23±0.05                     | IDLE/Throttle fully                                                                                                |
|                                                                                           | Battery Volt (V)                      |                | >12 V                         |                                                                                                                    |
|                                                                                           | Idle Speed Set point (RPM)            |                | ---                           |                                                                                                                    |
|                                                                                           | ISCAdapMean (°)                       |                | ---                           |                                                                                                                    |
|                                                                                           | Accumulated Eng. Run Time (Hr)        |                | ---                           |                                                                                                                    |
| (Hot Engine) Before Repair                                                                | EngineSpeed IDLE(rpm)                 |                | 2000 ± 100 rpm                |                                                                                                                    |
|                                                                                           | MAPSample (kPa)                       |                | 52 ~ 68 kPa                   |                                                                                                                    |
|                                                                                           | Injection duration (ms)               |                | 1.4 ~ 2.5ms<br>/1.7~3ms(cold) |                                                                                                                    |
|                                                                                           | Ign. Advance (°)                      |                | 3 ~ 20 BTDC                   |                                                                                                                    |
|                                                                                           | Air Temp.(°C)                         |                | environ.temp ±2 °C            |                                                                                                                    |
|                                                                                           | Engine Temp. (°C)                     |                | >110 °C/>70°C(winter)         |                                                                                                                    |
|                                                                                           | O <sup>2</sup> sensor voltage (V)     |                | 0 ~ 1 V                       |                                                                                                                    |
|                                                                                           | O <sup>2</sup> sensor heater (Yes/no) |                | YES                           |                                                                                                                    |
|                                                                                           | O <sup>2</sup> sensor correct         |                | ±20%                          |                                                                                                                    |
|                                                                                           | ABVAngDurMech (°)                     |                | < 140 °                       | >140 ° The scooter with exchange engine oil and clean throttly body<br>>180 ° The scooter must clean throttly body |
| (Hot Engine) After Repair                                                                 | EngineSpeed IDLE(rpm)                 |                | 2000 ± 100 rpm                | 80~90°C                                                                                                            |
|                                                                                           | MAPSample (kPa)                       |                | 52 ~ 68 kPa                   | 80~90°C                                                                                                            |
|                                                                                           | Injection duration (ms)               |                | 1.4 ~ 2.5ms<br>/1.7~3ms(cold) | 80~90°C                                                                                                            |
|                                                                                           | Ign. Advance (°)                      |                | 3 ~ 20 BTDC                   | 80~90°C                                                                                                            |
|                                                                                           | Air Temp.(°C)                         |                | environ.temp ±2 °C            |                                                                                                                    |
|                                                                                           | Engine Temp. (°C)                     |                | >110 °C/>70°C(winter)         |                                                                                                                    |
|                                                                                           | O <sup>2</sup> sensor voltage (V)     |                | 0 ~ 1 V                       |                                                                                                                    |
|                                                                                           | O <sup>2</sup> sensor heater (Yes/no) |                | YES                           |                                                                                                                    |
|                                                                                           | O <sup>2</sup> sensor correct         |                | ±20%                          |                                                                                                                    |
|                                                                                           | ABVAngDurMech (°)                     |                | < 140 °                       | >140 ° The scooter with exchange engine oil and clean throttly body<br>>180 ° The scooter must clean throttly body |
| Repair description                                                                        |                                       | Repair Process |                               |                                                                                                                    |


## **5. FUEL INJECTION SYSTEM**

### FUEL INJECTION SYSTEM (E5+)

|                                |       |
|--------------------------------|-------|
| SYSTEM DIAGRAM .....           | 5 - 1 |
| SYSTEM LOCATION .....          | 5 - 2 |
| SERVICE INFORMATION .....      | 5 - 3 |
| TROUBLESHOOTING .....          | 5 - 4 |
| CHECK ENGINE LAMP (CELP) ..... | 5 - 5 |
| FAILURE CODES CHART .....      | 5 - 6 |
| FI DIAGNOSTIC TOOL .....       | 5 - 9 |
| DIAGNOSTIC REPORT .....        | 5-11  |

## 5. FUEL INJECTION SYSTEM


### INJECTION SYSTEM



## 5. FUEL INJECTION SYSTEM

### Parts Location

- 01: Inductive Ignition coil
- 02: Fuel pump
- 03: ECU
- 04: ETS sensor
- 05: Fuel Injector
- 06: T-MAP sensor
- 07: ISC
- 08: TPS
- 09: CPS
- 10: O<sub>2</sub> sensor



## 5. FUEL INJECTION SYSTEM

### SERVICE INFORMATION

#### GENERAL INSTRUCTIONS

\* Gasoline is very dangerous. When working with gasoline, keep sparks and flames away from the working area.  
 Gasoline is extremely flammable and is explosive under certain conditions. Be sure to work in a well-ventilated area.

- Disconnect the cables of the battery when the engine is running, which could lead to ECU damage.
- Connect the harness positive (+) cable to the battery negative (-) terminal or connect the harness negative (-) to the battery positive (+) terminal, which could lead to ECU damage.
- Always keep fuel over 750 cc in fuel tank.

#### SPECIFICATIONS

| Item                                           |                             |                      | Standard                                                   |
|------------------------------------------------|-----------------------------|----------------------|------------------------------------------------------------|
| Charging voltage of battery                    |                             |                      | 13.5 ~ 14.5V                                               |
| Voltage from the ECU to sensor                 |                             |                      | 5 ±0.1V                                                    |
| Fuel injector resistance (20 ℃/68 ℉)           |                             |                      | 12 ±0.6Ω                                                   |
| Engine temperature sensor resistance           |                             |                      | 11.529 ±10% kΩ(25 ℃)                                       |
| Throttle position sensor voltage               |                             |                      | Idle (0 °/ 0.51 ±0.1V)<br>Throttle fully (90 °/3.85V over) |
| Fuel pump pressure                             |                             |                      | 2.5bar                                                     |
| Fuel unit resistance (20 ℃/68 ℉)               |                             |                      | F: about 100Ω    E: about 1100Ω                            |
| O2 sensor                                      | O2 sensor heater resistance |                      | 15Ω                                                        |
|                                                | Voltage                     | Air/Fuel<14.7 (Rich) | >0.7V                                                      |
|                                                |                             | Air/Fuel>14.7 (Lean) | <0.18V                                                     |
| Crank position sensor (Pulser) resistance      |                             |                      | 107 ~ 119Ω                                                 |
| Inductive ignition coil resistance (20 ℃/68 ℉) |                             |                      | 0.60 ~ 0.66Ω                                               |
| Idle speed                                     |                             |                      | 2000 ± 100 rpm                                             |



## **5. FUEL INJECTION SYSTEM**

### **TROUBLESHOOTING**

#### **Engine won't start**

- Battery voltage too low
- Fuel level too low
- Pinched or clogged fuel hose
- Faulty fuel pump operating system
- Clogged fuel filter (fuel pump)
- Clogged fuel injector
- Faulty spark plug or wrong type
- Cut by ECU due to angle detect sensor or incorrect function

#### **Backfiring or misfiring during acceleration**

- Ignition system malfunction

#### **Poor performance (drive ability) and poor fuel economy**

- Pinched or clogged fuel hose
- Faulty fuel injector

#### **Engine stall, hard to start, rough idling**

- Intake air leak
- Fuel contaminated/deteriorated
- Pinched or clogged fuel hose
- Idle speed misadjusted


## 5. FUEL INJECTION SYSTEM

### CHECK ENGINE LAMP (CEL)

Open the Ignition switch, the CELP indicator will illuminate always.

After starting it will crush out.

If there is any malfunction, the CELP indicator will still illuminate, please take your scooter to a KYMCO dealer for service as soon as possible.



## 5. FUEL INJECTION SYSTEM

### Failure Code Chart

| No | Diagnose code | Failure Code | Pcode                                                                  |  |
|----|---------------|--------------|------------------------------------------------------------------------|--|
| 1  | D1            | B0099        | B0099 Roll sensor Voltage High                                         |  |
| 2  | F0            | C0064        | C0064 Roll sensor malfunction                                          |  |
| 3  | A1            | P0030        | P0030 O2 sensor heater malfunction                                     |  |
| 4  | A2            | P0031        | P0031 O2 sensor heater Voltage Low                                     |  |
| 5  | A3            | P0032        | P0032 Lambda sensor heater Voltage High                                |  |
| 6  | A4            | P0105        | P0105 MAP sensor malfunction                                           |  |
| 7  | A5            | P0107        | P0107 MAP sensor Voltage Low                                           |  |
| 8  | A6            | P0108        | P0108 MAP sensor Voltage High                                          |  |
| 9  | A7            | P0110        | P0110 Intake air temperature sensor malfunction or Voltage High        |  |
| 10 | A8            | P0111        | P0111 Intake air temperature circuit malfunction                       |  |
| 11 | A9            | P0112        | P0112 Intake air temperature sensor Voltage Low                        |  |
| 12 | D6            | P0113        | P0113 Intake air temperature sensor Voltage High                       |  |
| 13 | AA            | P0114        | P0114 Intake air temperature intermittent failure                      |  |
| 14 | AB            | P0115        | P0115 Engine Temperature Sensor malfunction or Voltage High            |  |
| 15 | AC            | P0117        | P0117 Engine Temperature Sensor Voltage Low                            |  |
| 16 | AD            | P0118        | P0118 Engine Temperature Sensor Voltage High                           |  |
| 17 | AE            | P0119        | P0119 Engine Temperature intermittent failure                          |  |
| 18 | AF            | P0120        | P0120 Throttle Position Sensor malfunction or Voltage Low              |  |
| 19 | B0            | P0121        | P0121 Throttle position sensor adaptation is out of range              |  |
| 20 | B1            | P0122        | P0122 Throttle Position Sensor Voltage Low                             |  |
| 21 | B2            | P0123        | P0123 Throttle Position Sensor Voltage High                            |  |
| 22 | B3            | P0124        | P0124 Difference between the two last TPS acquisitions is out of range |  |
| 23 | B4            | P0130        | P0130 O2 sensor signal malfunction                                     |  |
| 24 | B5            | P0131        | P0131 O2 sensor signal Voltage Low                                     |  |
| 25 | B6            | P0132        | P0132 O2 sensor signal Voltage High                                    |  |
| 26 | D7            | P0171        | P0171 System over lean or over rich (Too Lean)                         |  |
| 27 | D8            | P0172        | P0172 System over lean or over rich (Too Rich)                         |  |
| 28 | B7            | P0200        | P0200 Injection malfunction                                            |  |
| 29 | DA            | P0201        | P0201 Injection valve malfunction                                      |  |
| 30 | B8            | P0217        | P0217 Engine over temperature condition                                |  |
| 31 | B9            | P0219        | P0219 CVT overspeed detected                                           |  |
| 32 | BA            | P0230        | P0230 Fuel pump malfunction                                            |  |
| 33 | BB            | P0231        | P0231 Fuel pump Voltage Low                                            |  |
| 34 | BC            | P0232        | P0232 Fuel pump Voltage High                                           |  |
| 35 | BD            | P0260        | P0260 Injection valve malfunction                                      |  |
| 36 | BE            | P0261        | P0261 Injection valve Voltage Low                                      |  |
| 37 | BF            | P0262        | P0262 Injection valve Voltage High                                     |  |


## 5. FUEL INJECTION SYSTEM

|    |    |       |                                                               |  |
|----|----|-------|---------------------------------------------------------------|--|
| 38 | BE | P0264 | P0264 Injection valve Voltage Low                             |  |
| 39 | BF | P0265 | P0265 Injection valve Voltage High                            |  |
| 40 | C0 | P0335 | P0335 Crankshaft sensor malfunction                           |  |
| 41 | C1 | P0350 | P0350 Ignition malfunction or Voltage Low                     |  |
| 42 | C2 | P0351 | P0351 Ignition Voltage High                                   |  |
| 43 | DB | P0412 | P0412 Secondary air injection system malfunction              |  |
| 44 | C3 | P0480 | P0480 Fan Relay/Circuit malfunction                           |  |
| 45 | F1 | P0484 | P0484 Fan Relay/Circuit Voltage High                          |  |
| 46 | F2 | P0485 | P0485 Fan Relay/Circuit Voltage Low                           |  |
| 47 | DE | P0500 | P0500 Vehicle Speed Sensor malfunction                        |  |
| 48 | D9 | P0501 | P0501 Vehicle Speed Sensor malfunction                        |  |
| 49 | C4 | P0505 | P0505 ISAV idle speed actuator valve malfunction              |  |
| 50 | C5 | P0508 | P0508 ISAV idle speed actuator valve Voltage Low              |  |
| 51 | C6 | P0509 | P0509 ISAV idle speed actuator valve Voltage High             |  |
| 52 | DF | P0511 | P0511 ISC stepper motor malfunction                           |  |
| 53 | F3 | P0560 | P0560 Battery voltage VBK malfunction                         |  |
| 54 | F4 | P0561 | P0561 Battery voltage VBK malfunction                         |  |
| 55 | C7 | P0562 | P0562 Battery voltage VBK too Low                             |  |
| 56 | C8 | P0563 | P0563 Battery voltage VBK too High                            |  |
| 57 | DC | P0603 | P0603 ECU memory error                                        |  |
| 58 | F7 | P0615 | P0615 Starter Relay malfunction                               |  |
| 59 | F8 | P0616 | P0616 Starter Relay Voltage Low                               |  |
| 60 | F9 | P0617 | P0617 Starter Relay Voltage High                              |  |
| 61 | C9 | P0650 | P0650 MIL Voltage High                                        |  |
| 62 | CA | P0700 | P0700 Engine overspeed detected                               |  |
| 63 | CB | P1110 | P1110 Roll sensor Voltage High                                |  |
| 64 | CC | P1111 | P1111 Roll sensor malfunction or Voltage Low                  |  |
| 65 | DD | P1205 | P1205 MAP sensor malfunction                                  |  |
| 66 | CD | P1410 | P1410 AISV system break down                                  |  |
| 67 | E0 | P1505 | P1505 ISC system malfunction                                  |  |
| 68 | E1 | P1521 | P1521 VACS Valve circuit malfunction                          |  |
| 69 | CE | P1630 | P1630 Roll sensor circuit malfunction                         |  |
| 70 | CF | P2187 | P2187 Lambda control too High                                 |  |
| 71 | D0 | P2188 | P2188 Lambda control too Low                                  |  |
| 72 | D4 | P2300 | P2300 Ignition malfunction or Voltage Low                     |  |
| 73 | D5 | P2301 | P2301 Ignition malfunction or Voltage High                    |  |
| 74 | D4 | P2303 | P2303 Ignition malfunction or Voltage Low                     |  |
| 75 | D5 | P2304 | P2304 Ignition malfunction or Voltage High                    |  |
| 76 | D3 | P263A | P263A MIL Voltage Low                                         |  |
| 77 | D2 | P263B | P263B MIL Voltage High                                        |  |
| 78 |    | C006A | C006A Accelerometer identifier diagnosis Failure of self test |  |

## 5. FUEL INJECTION SYSTEM

|     |  |       |                                                                                              |  |
|-----|--|-------|----------------------------------------------------------------------------------------------|--|
| 79  |  | P0106 | P0106 Stuck MAP signal                                                                       |  |
| 80  |  | P0116 | P0116 TCO out of range                                                                       |  |
| 81  |  | P0133 | P0133 Oxygen sensor switching time monitoring Implausible oxygen sensor switching time       |  |
| 82  |  | P0134 | P0134 Lambda sensor diagnosis Open signal                                                    |  |
| 83  |  | P0135 | P0135 Lambda sensor heater plausibility diagnosis Lambda sensor heater implausible operation |  |
| 84  |  | P016B | P016B Lambda controller Excessive positive deviation of lambda controller                    |  |
| 85  |  | P016C | P016C Lambda controller Excessive negative deviation of lambda controller                    |  |
| 86  |  | P0300 | P0300 Multiple misfire A diagnosis                                                           |  |
| 87  |  | P0313 | P0313 Misfire fuel tank low                                                                  |  |
| 88  |  | P0314 | P0314 Misfire A diagnosis                                                                    |  |
| 89  |  | P0336 | P0336 Crankshaft wrong tooth number diagnosis Additional CRK tooth detected                  |  |
| 90  |  | P0339 | P0339 Crankshaft sensor Additional edges inside filtering period                             |  |
| 91  |  | P0410 | P0410 Secondary Air Valve Plausibility diagnosis Secondary Air Valve Unplausible             |  |
| 92  |  | P0413 | P0413 Secondary air valve diagnosis Open signal                                              |  |
| 93  |  | P0414 | P0414 Secondary air valve diagnosis Signal shorted to ground                                 |  |
| 94  |  | P0444 | P0444 Canister purge solenoid diagnosis Open signal                                          |  |
| 95  |  | P0458 | P0458 Canister purge solenoid diagnosis Signal shorted to ground                             |  |
| 96  |  | P0459 | P0459 Canister purge solenoid diagnosis Signal shorted to battery                            |  |
| 97  |  | P0503 | P0503 Intermittent vehicle speed signal from CAN diagnosis                                   |  |
| 98  |  | P0519 | P0519 Stepper plausibility diagnosis Implausible stepper control                             |  |
| 99  |  | P0661 | P0661 Variable intake pipe diagnosis Signal shorted to battery                               |  |
| 100 |  | P0662 | P0662 Variable intake pipe diagnosis Signal shorted to ground                                |  |
| 101 |  | P0663 | P0663 Variable intake pipe diagnosis Signal open                                             |  |
| 102 |  | P0894 | P0894 CVT overspeed Transmission component slipping                                          |  |
| 103 |  | P2A00 | P2A00 Oxygen sensor out of range                                                             |  |
| 104 |  | U0241 | U0241 Head lamp diagnosis Signal shorted to ground                                           |  |
| 105 |  | U1601 | U1601 CAN Bus off diagnosis Bus off                                                          |  |
| 106 |  | U1605 | U1605 CAN control unit diagnosis for checked received messages Fail                          |  |
| 107 |  | P0643 | P0643 Reference voltage diagnosis 1 Signal shorted to battery                                |  |
| 108 |  | P0608 | P0608 Reference voltage diagnosis 1 Signal shorted to ground or open                         |  |

# Fi Diagnostic Tool Operation Instructions Part No. 3620A LEB2 E00



- |                                 |                |
|---------------------------------|----------------|
| 1 Model No.                     | 6 UP Button    |
| 2 Down Button                   | 7 DATA Analyze |
| 3 DTC indicator (Failure codes) | 8 DTC Inspect  |
| 4 Enter or Exit                 | 9 ECU Version  |
| 5 Power indicator               |                |

### Note:

Use the sub-cord, OBD diagnostics, connector (part number:36205-LGC6- E00) to connect between vehicle and diagnostic tool.



## 5. FUEL INJECTION SYSTEM

### DTC INSPECTION

Connect Fi diagnostic tool with the connector of harness wire located beside the Battery.

- \*.Fi diagnostic tool is electrically After Connect Fi diagnostic tool with the connector of harness,
  - The data can only be read after the main switch is turned on




Connector

Press the "Enter" button

### VERSION INSPECTION

Check the software version

Press the "Enter" button and then turn to the first page.



### DTC INSPECTION

Press the "Down" button to enter the DTC Inspect.



### DATA ANALYSIS INSPECTION

Press the "Down" button to enter the DTC Inspect.





## 5. FUEL INJECTION SYSTEM

### SUPER 8 50 E5 +Diagnostic report

| <b>SF :</b>                                                                               |                                       | <b>Customer :</b>     |                                                                                                                   | <b>Eng. No:</b>                                                          |  |
|-------------------------------------------------------------------------------------------|---------------------------------------|-----------------------|-------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------|--|
| <b>Production Date :</b>                                                                  |                                       | <b>Service Date :</b> |                                                                                                                   | <b>Mileage :</b>                                                         |  |
| Reason of repair: <input type="checkbox"/> Maintenance <input type="checkbox"/> Breakdown |                                       |                       |                                                                                                                   |                                                                          |  |
| Item                                                                                      |                                       | Data                  | Reference                                                                                                         | Memo                                                                     |  |
| <b>ECU Version</b>                                                                        | ECU No                                |                       |                                                                                                                   | BLA2                                                                     |  |
|                                                                                           | Hardware Ver                          |                       |                                                                                                                   |                                                                          |  |
|                                                                                           | Software Ver                          |                       |                                                                                                                   |                                                                          |  |
|                                                                                           | Calibration Ver                       |                       | E5BLA2EUA A                                                                                                       |                                                                          |  |
| <b>DTC</b>                                                                                | Active                                |                       |                                                                                                                   |                                                                          |  |
|                                                                                           | Occurred                              |                       |                                                                                                                   |                                                                          |  |
|                                                                                           | History                               |                       |                                                                                                                   |                                                                          |  |
| <b>(Cool Engine) Engine Stop</b>                                                          | Air Temp.( °C)                        |                       | Environ temp ±2 °C                                                                                                |                                                                          |  |
|                                                                                           | Engine Temp.(Cooling)                 |                       | Environ temp ±2 °C                                                                                                |                                                                          |  |
|                                                                                           | Atom. Pressure (kpa.)                 |                       | 101.3 ±3 kpa                                                                                                      | The ambient pressure drop about 12kpa at the altitude every 1000m raised |  |
|                                                                                           | Throttle Position (%)                 |                       | 0° / >90°                                                                                                         | IDLE/Throttle fully                                                      |  |
|                                                                                           | Throttle Position (V)                 |                       | 0.51 ±0.1V / >3.85V                                                                                               | IDLE/Throttle fully                                                      |  |
|                                                                                           | TPI Idle Mean (V)                     |                       | 0.51 ±0.1V                                                                                                        |                                                                          |  |
|                                                                                           | Battery Volt (V)                      |                       | >12 V                                                                                                             |                                                                          |  |
| <b>(Hot Engine) Before Repair</b>                                                         | Engine Speed IDLE(rpm)                |                       | 2000 ± 100 rpm                                                                                                    |                                                                          |  |
|                                                                                           | Battery Volt (V)                      |                       | >13 V                                                                                                             |                                                                          |  |
|                                                                                           | MAPSample (kPa)                       |                       | 50~ 65 kpa                                                                                                        |                                                                          |  |
|                                                                                           | Injection duration (ms)               |                       | 1.6~2.8ms                                                                                                         |                                                                          |  |
|                                                                                           | Ign. Advance (°)                      |                       | 2~16BTDC                                                                                                          |                                                                          |  |
|                                                                                           | Air Temp.( °C)                        |                       | environ.temp ±2 °C                                                                                                |                                                                          |  |
|                                                                                           | Engine Temp. ( °C)                    |                       | >110 °C                                                                                                           |                                                                          |  |
|                                                                                           | O <sup>2</sup> sensor voltage (V)     |                       | 0 ~ 1 V                                                                                                           |                                                                          |  |
|                                                                                           | O <sup>2</sup> sensor heater (Yes/no) |                       | YES                                                                                                               |                                                                          |  |
|                                                                                           | O <sup>2</sup> sensor correct         |                       | -14%~15%                                                                                                          |                                                                          |  |
| ISC AngDurMech (°)                                                                        |                                       | 15%<ISC< 45%          | >45% The scooter with exchange engine oil and clean throttlly body<br>>50% °The scooter must clean throttlly body |                                                                          |  |
| <b>(Hot Engine) After Repair</b>                                                          | Engine Speed IDLE(rpm)                |                       | 2000 ± 100 rpm                                                                                                    |                                                                          |  |
|                                                                                           | Battery Volt (V)                      |                       | >13 V                                                                                                             |                                                                          |  |
|                                                                                           | MAPSample (kPa)                       |                       | 50~ 65 kpa                                                                                                        |                                                                          |  |
|                                                                                           | Injection duration (ms)               |                       | 1.6~2.8ms                                                                                                         |                                                                          |  |
|                                                                                           | Ign. Advance (°)                      |                       | 2~16BTDC                                                                                                          |                                                                          |  |
|                                                                                           | Air Temp.( °C)                        |                       | environ.temp ±2 °C                                                                                                |                                                                          |  |
|                                                                                           | Engine Temp. ( °C)                    |                       | >110 °C                                                                                                           |                                                                          |  |
|                                                                                           | O <sup>2</sup> sensor voltage (V)     |                       | 0 ~ 1 V                                                                                                           |                                                                          |  |
|                                                                                           | O <sup>2</sup> sensor heater (Yes/no) |                       | YES                                                                                                               |                                                                          |  |
|                                                                                           | O <sup>2</sup> sensor correct         |                       | -14%~15%                                                                                                          |                                                                          |  |
| ISC AngDurMech (°)                                                                        |                                       | 15%<ISC< 45%          | >45% The scooter with exchange engine oil and clean throttlly body<br>>50% °The scooter must clean throttlly body |                                                                          |  |

ENGINE REMOVAL/INSTALLATION

SERVICE INFORMATION ..... 6-2


ENGINE REMOVAL..... 6-3

ENGINE INSTALLATION ..... 6-6

## 6. ENGINE REMOVAL/INSTALLATION



SUPER 8 50



### SERVICE INFORMATION

#### GENERAL INSTRUCTIONS

- A jack or other adjustable support is required to support and maneuver the engine. Be careful not to damage the motorcycle body, cables and wires during engine removal.
- Use towels to protect the motorcycle body during engine removal.
- Drain the coolant before removing the engine.
- After the engine is installed, fill the cooling system with coolant and be sure to bleed air. Start the engine to check for coolant leaks.
- Before removing the engine, the rear brake caliper must be removed first. Be careful not to bend or twist the brake fluid tube.

#### SPECIFICATIONS


Engine oil capacity: 0.9 Liter

#### TORQUE VALUES


|                                                    |         |
|----------------------------------------------------|---------|
| Rear shock absorber upper mount bolt               | 40 N-m  |
| Rear shock absorber lower mount bolt               | 40 N-m  |
| Rear axle nut                                      | 120 N-m |
| Engine hanger bolt (frame side)                    | 50 N-m  |
| Engine hanger bolt (ENG. side)                     | 50 N-m  |
| Rear caliper holder bolt                           | 27 N-m  |
| Exhaust muffler pipe nut                           | 20 N-m  |
| Exhaust muffler bracket bolt (attached to RR Fork) | 35 N-m  |
| Rear fork bolt (attached to ENG case)              | 32 N-m  |

### ENGINE REMOVAL

Remove the frame body cover(2-4/5).  
Disconnect the battery negative cable.  
Disconnect the engine negative cable.  
Disconnect the A.C. Generator wire connector.  
Disconnect the starter motor cable from the starter relay.




Remove the spark plug cap.  
Remove the ignition coil's wire.  
Remove the O2 sensor wire.



Disconnect the ECU connector  
Disconnect the engine temperature sensor connector.  
Remove the injector's wire.  
Remove the throttle cable.  
Remove the vacuum tube.  
Remove the Crankcase Breather Tube.  
Remove the fuel tube attaching to injector.

There are two Anti-modification Bolts attaching to the throttle body. If you to remove the throttle body or ECU, you need special tools as below.



## 6. ENGINE REMOVAL/INSTALLATION


Remove the air cleaner




Remove the exhaust muffler(2-6)




Remove the rear brake caliper.  
Remove one bolt attaching to rear brake  
hose clamps.



Remove the right and left rear shock absorbers  
mounting bolts.



Remove the engine mounting bolt and pull out the engine with the engine hanger bracket backward.




Engine Hanger  
Bracket Bolt

Engine Mounting Bolt

### **ENGINE HANGER BRACKET REMOVAL**

Remove the engine hanger bracket bolt and nut.  
Remove the engine.

Inspect the engine hanger bushings and stopper rubbers for wear or damage.






### ENGINE HANGER BRACKET

#### INSTALLATION

Install the engine hanger bracket to the engine.  
Install and tighten the engine hanger bracket bolts.



Engine Hanger  
Bracket Bolt

Engine Mounting Bolt

### ENGINE INSTALLATION

Install the engine and tighten the engine mounting bolts.

**Torque:** 5.0kg-m

Tighten the rear shock absorbers mounting bolts.

**Torque:** Up side 4.0kg-m

Down side 2.5kg-m

Install the removed parts in the reverse order of removal.

\*


**Tire pressure should be checked when tires are cold.**




After installation, inspect and adjust the following:

Throttle grip free play (⇒3-3)

# 7. CYLINDER HEAD/VALVES



7



## 7. CYLINDER HEAD/VALVES

|                             |     |                                 |     |
|-----------------------------|-----|---------------------------------|-----|
| SERVICE INFORMATION.....    | 7-1 | CYLINDER HEAD DISASSEMBLY ..... | 7-7 |
| TROUBLESHOOTING.....        | 7-2 | CYLINDER HEAD ASSEMBLY .....    | 7-8 |
| CAMSHAFT REMOVAL.....       | 7-3 | CYLINDER HEAD INSTALLATION..... | 7-8 |
| CYLINDER HEAD REMOVAL ..... | 7-5 | CAMSHAFT INSTALLATION .....     | 7-9 |

### SERVICE INFORMATION

#### GENERAL INSTRUCTIONS

- The cylinder head can be serviced with the engine installed in the frame.
- When assembling, apply molybdenum disulfide grease or engine oil to the valve guide movable parts, valve arm and camshaft sliding surfaces for initial lubrication.
- The camshaft is lubricated by engine oil through the cylinder head engine oil passages. Clean and unclog the oil passages before assembling the cylinder head.
- After disassembly, clean the removed parts and dry them with compressed air before inspection.
- After removal, mark and arrange the removed parts in order. When assembling, install them in the reverse order of removal.

#### SPECIFICATIONS

| Item                               |    | Standard (mm)        | Service Limit (mm) |
|------------------------------------|----|----------------------|--------------------|
| Valve clearance (cold)             | IN | 0.10                 | —                  |
|                                    | EX | 0.10                 | —                  |
| Cylinder head compression pressure |    | 14kg/cm <sup>2</sup> |                    |
| Cylinder head warpage              |    | —                    | 0.05               |
| Camshaft cam height                | IN | 25.706               | 25.306             |
|                                    | EX | 25.564               | 25.164             |
| Valve rocker arm I.D.              | IN | 10.000~10.015        | 10.10              |
|                                    | EX | 10.000~10.015        | 10.10              |
| Valve rocker arm shaft O.D.        | IN | 9.972~9.987          | 9.91               |
|                                    | EX | 9.972~9.987          | 9.91               |
| Valve seat width                   | IN | 1.0                  | 1.8                |
|                                    | EX | 1.0                  | 1.8                |
| Valve stem O.D.                    | IN | 4.975~4.990          | 4.90               |
|                                    | EX | 4.955~4.970          | 4.90               |
| Valve guide I.D.                   | IN | 5.000~5.012          | 5.03               |
|                                    | EX | 5.000~5.012          | 5.03               |
| Valve stem-to-guide clearance      | IN | 0.010~0.037          | 0.08               |
|                                    | EX | 0.030~0.057          | 0.10               |

## 7. CYLINDER HEAD/VALVES

---

### TORQUE VALUES

|                               |              |                             |
|-------------------------------|--------------|-----------------------------|
| Cylinder head nut             | 1.8~2.2kgf-m | Apply engine oil to threads |
| Valve clearance adjusting nut | 0.7~1.1kgf-m | Apply engine oil to threads |

### SPECIAL TOOLS

Valve spring compressor

### TROUBLESHOOTING

- The poor cylinder head operation can be diagnosed by a compression test or by tracing engine top-end noises.

#### Poor performance at idle speed

- Compression too low

#### Compression too low

- Incorrect valve clearance adjustment
- Burned or bent valves
- Incorrect valve timing
- Broken valve spring
- Poor valve and seat contact
- Leaking cylinder head gasket
- Warped or cracked cylinder head
- Poorly installed spark plug

#### Compression too high

- Excessive carbon build-up in combustion chamber

#### White smoke from exhaust muffler

- Worn valve stem or valve guide
- Damaged valve stem seal

#### Abnormal noise

- Incorrect valve clearance adjustment
- Sticking valve or broken valve spring
- Damaged or worn camshaft
- Worn cam chain guide
- Worn camshaft and rocker arm

## 7. CYLINDER HEAD/VALVES

### CAMSHAFT REMOVAL


Remove the center cover.  
Remove the four cylinder head cover bolts to remove the cylinder head cover.  
Remove the two nuts attaching the secondary air inlet tube.

Remove the cam chain tensioner cap screw and the O-ring.


Turn the cam chain tensioner screw clockwise to tighten it.

Turn the flywheel counterclockwise so that the "T" mark on the flywheel aligns with the index mark on the crankcase to bring the round hole on the camshaft gear facing up to the top dead center on the compression stroke.


Cylinder Head Cover



O-ring




Screw



Tensioner Screw

Camshaft Gear




Round Hole

Punch Marks

## 7. CYLINDER HEAD/VALVES


Remove the two cylinder head bolts.  
Remove the four cylinder head nuts and washers.

\* Diagonally loosen the cylinder head nuts in 2 or 3 times.




Washer

Remove the camshaft holder and dowel pins.



Remove the camshaft gear from the cam chain and remove the camshaft.



### CAMSHAFT INSPECTION

Check each cam lobe for wear or damage.  
Measure the cam lobe height.

#### Service Limits:


IN : 26.038mm replace if below

EX: 25.407mm replace if below




## 7. CYLINDER HEAD/VALVES

Check each camshaft bearing for play or damage. Replace the camshaft assembly with a new one if the bearings are noisy or have excessive play.



### CAMSHAFT HOLDER DISASSEMBLY

Take out the valve rocker arm shafts using a 5mm bolt.  
Remove the valve rocker arms.




Rocker Arm    Rocker Arm Shaft    5mm Bolt

### CAMSHAFT HOLDER INSPECTION

Inspect the camshaft holder, valve rocker arms and rocker arm shafts for wear or damage.

\* If the valve rocker arm contact surface is worn, check each cam lobe for wear or damage.

Camshaft Holder



Rocker Arm Shafts



Measure the I.D. of each valve rocker arm.

#### Service Limits:

IN: 10.10mm replace if over

EX: 10.10mm replace if over

Measure each rocker arm shaft O.D.

#### Service Limits:

IN: 9.91mm replace if over

EX: 9.91mm replace if over



## 7. CYLINDER HEAD/VALVES

### CYLINDER HEAD REMOVE

Remove the camshaft.  
Remove the carburetor.  
Remove the exhaust muffler.  
Remove the carburetor intake manifold.  
Remove the cooling fan cover.  
Remove the engine cover bolts and screws.  
Separate the engine cover joint claws.


Remove the cylinder head.

Remove the dowel pins and cylinder head gasket.  
Remove the cam chain guide.


Remove all gasket material from the cylinder mating surface.

- \***
- Avoid damaging the cylinder mating surface.
  - Be careful not to drop any gasket material into the engine.

Intake Manifold




Cylinder Head




Bolts

Dowel Pins

Cylinder Head Gasket



Cam Chain Guide



## 7. CYLINDER HEAD/VALVES


### CYLINDER HEAD DISASSEMBLY

Remove the valve spring cotters, retainers, springs, spring seats and valve stem seals using a valve spring compressor.

- \* Be sure to compress the valve springs with a valve spring compressor.
- \* Mark all disassembled parts to ensure correct reassembly.

Special


Valve Spring Compressor



Remove carbon deposits from the combustion chamber.

Clean off any gasket material from the cylinder head mating surface.

- \* Be careful not to damage the cylinder head mating surface.




### INSPECTION

#### CYLINDER HEAD

Check the spark plug hole and valve areas for cracks.

Check the cylinder head for warpage with a straight edge and feeler gauge.

**Service Limit:** 0.05mm repair or replace if over




#### VALVE SPRING FREE LENGTH

Measure the free length of the inner and outer valve springs.

**Service Limits:**

Inner : 30.1mm replace if below

Outer : 33.3mm replace if below



## 7. CYLINDER HEAD/VALVES

### VALVE /VALVE GUIDE

Inspect each valve for bending, burning, scratches or abnormal stem wear.


Check valve movement in the guide.

Measure each valve stem O.D.

#### Service Limits:

IN : 4.90mm replace if below

EX: 4.90mm replace if below



Measure each valve guide I.D.

**Service Limits:** IN : 5.03mm replace if over


EX: 5.03mm replace if over

Subtract each valve stem O.D. from the corresponding guide I.D. to obtain the stem-to-guide clearance.

**Service Limits:** IN : 0.08mm replace if over

EX: 0.10mm replace if over

\* If the stem-to-guide clearance exceeds the service limits, replace the cylinder head as necessary.



### CYLINDER HEAD ASSEMBLY

Install the valve spring seats and valve stem seals.

\* Be sure to install new valve stem seals.

Lubricate each valve stem with engine oil and insert the valves into the valve guides.

Install the valve springs and retainers.




Compress the valve springs using the valve spring compressor, then install the valve cotters.

\* • When assembling, a valve spring compressor must be used.  
• Install the cotters with the pointed ends facing down from the upper side of the cylinder head.

Special

Valve Spring Compressor



## 7. CYLINDER HEAD/VALVES

Tap the valve stems gently with a plastic hammer for 2~3 times to firmly seat the cotteners.

\* Be careful not to damage the valves.




### CYLINDER HEAD INSTALLATION

Tighten the four stud bolts.

Install the dowel pins and a new cylinder head gasket.

Install the cam chain guide.


**Torque:** Stud Bolts :0.7~1.1kg-m



Stud Bolts

Cam Chain Guide

Install the cylinder head.



Cylinder Head


### CAMSHAFT HOLDER ASSEMBLY

Install the exhaust valve rocker arm to the "EX" mark side of the camshaft holder.

Install the intake valve rocker arm and the rocker arm shafts.

- \* • Align the cutout on the front end of the intake valve rocker arm shaft with the bolt of the camshaft holder.  
• Align the cross cutout on the exhaust valve rocker arm shaft with the bolt of the camshaft holder.

Camshaft Holder



Valve Rocker Arm


## 7. CYLINDER HEAD/VALVES

### CAMSHAFT INSTALLATION


Turn the flywheel so that the “T” mark on the flywheel aligns with the index mark on the crankcase.

Keep the round hole on the camshaft gear facing up and align the punch marks on the camshaft gear with the cylinder head surface (Position the intake and exhaust cam lobes down.) and install the camshaft onto the cylinder head.

Install the cam chain over the camshaft gear.



Install the dowel pins.




Install the camshaft holder, washers and nuts on the cylinder head.

Tighten the four cylinder head nuts and two bolts.


**Torque:** Cylinder head nut: 2.0kg-m

- \*
- Apply engine oil to the threads of the cylinder head nuts.
  - Diagonally tighten the cylinder head nuts in 2~3 times.



Adjust the valve clearance.

Turn the cam chain tensioner screw counter-clockwise to release it.




## 7. CYLINDER HEAD/VALVES

Apply engine oil to a new O-ring and install it.

Tighten the cam chain tensioner cap screw.


- \* Be sure to install the O-ring into the groove properly.



O-ring


Install a new cylinder head cover O-ring and install the cylinder head cover. Install and tighten the cylinder head cover bolts.

- \* Be sure to install the O-ring into the groove properly.



Cylinder Head Cover

## 8. CYLINDER/PISTON



8



## 8. CYLINDER/PISTON

|                           |     |                             |     |
|---------------------------|-----|-----------------------------|-----|
| SERVICE INFORMATION ..... | 8-1 | PISTON REMOVAL .....        | 8-2 |
| TROUBLESHOOTING .....     | 8-1 | PISTON INSTALLATION .....   | 8-6 |
| CYLINDER REMOVAL .....    | 8-2 | CYLINDER INSTALLATION ..... | 8-6 |

### SERVICE INFORMATION

#### GENERAL INSTRUCTIONS

- The cylinder and piston can be serviced with the engine installed in the frame.
- After disassembly, clean the removed parts and dry them with compressed air before inspection.

#### SPECIFICATIONS

| Item                               |                                |               | Standard (mm)            | Service Limit (mm) |
|------------------------------------|--------------------------------|---------------|--------------------------|--------------------|
| Cylinder                           | I.D.                           |               | 39.00-39.01              | 39.1               |
|                                    | Warpage                        |               | —                        | 0.05               |
|                                    | Cylindricity                   |               | —                        | 0.05               |
|                                    | True roundness                 |               | —                        | 0.05               |
| Piston,<br>piston ring             | Ring-to-groove<br>clearance    | Top           | 0.015-0.050              | 0.09               |
|                                    |                                | Second        | 0.015-0.050              | 0.09               |
|                                    | Ring end gap                   | Top           | 0.06-0.16                | 0.45               |
|                                    |                                | Second        | 0.13-0.28                | 0.45               |
|                                    |                                | Oil side rail | 0.20-0.70                | —                  |
|                                    | Piston O.D.                    |               | 38.855-38.875            | 38.8               |
|                                    | Piston O.D. measuring position |               | 8mm from bottom of skirt | —                  |
|                                    | Piston-to-cylinder clearance   |               | 0.010-0.040              | 0.1                |
|                                    | Piston pin hole I.D.           |               | 13.002-13.008            | 13.04              |
| Piston pin O.D                     |                                |               | 12.994-13.000            | 12.96              |
| Piston-to-piston pin clearance     |                                |               | 0.002-0.014              | —                  |
| Connecting rod small end I.D. bore |                                |               | 13.016-13.034            | 13.06              |

### TROUBLESHOOTING

- When hard starting or poor performance at low speed occurs, check the crankcase breather for white smoke. If white smoke is found, it means that the piston rings are worn, stuck or broken.

#### Compression too low or uneven compression

- Worn, stuck or broken piston rings
- Worn or damaged cylinder and piston

#### Compression too high

- Excessive carbon build-up in combustion chamber or on piston head

#### Excessive smoke from exhaust muffler

- Worn or damaged piston rings
- Worn or damaged cylinder and piston


#### Abnormal noisy piston

- Worn cylinder, piston and piston rings
- Worn piston pin hole and piston pin


## 8. CYLINDER/PISTON

### CYLINDER REMOVAL

Remove the cylinder head.  
Remove the cam chain guide.  
Remove the cylinder base bolts.  
Remove the cylinder.



Remove the cylinder gasket and dowel pins.  
Clean any gasket material from the cylinder surface.




### PISTON REMOVAL

Remove the piston pin clip.

\* Place a clean shop towel in the crankcase to keep the piston pin clip from falling into the crankcase.

Press the piston pin out of the piston and remove the piston.



Piston Rings      Piston

## 8. CYLINDER/PISTON

Inspect the piston, piston pin and piston rings.  
Remove the piston rings.

- \* Take care not to damage or break the piston rings during removal.

Clean carbon deposits from the piston ring grooves.



Install the piston rings onto the piston and measure the piston ring-to-groove clearance.

**Service Limits:**

**Top:** 0.09mm replace if over

**2nd:** 0.09mm replace if over




Remove the piston rings and insert each piston ring into the cylinder bottom.

- \* Use the piston head to push each piston ring into the cylinder.


Measure the piston ring end gap.

**Service Limit:** 0.45mm replace if over



Measure the piston pin hole I.D.


**Service Limit:** 13.04mm replace if over



## 8. CYLINDER/PISTON

Measure the piston pin O.D.

**Service Limit:** 12.96mm replace if below




Measure the piston O.D.

- \* Take measurement at 9mm from the bottom and 90° to the piston pin hole.

**Service Limit:** 38.9mm replace if below

Measure the piston-to-piston pin clearance.

**Service Limit:** 0.02mm replace if over



### CYLINDER INSPECTION

Inspect the cylinder bore for wear or damage. Measure the cylinder I.D. at three levels of top, middle and bottom at 90° to the piston pin (in both X and Y directions).

**Service Limit:** 39.10mm repair or replace if over

Measure the cylinder-to-piston clearance.

**Service Limit:** 0.1mm repair or replace if over




The true roundness is the difference between the values measured in X and Y directions. The cylindricity (difference between the values measured at the three levels) is subject to the maximum value calculated.

**Service Limits:**

**True Roundness:** 0.05mm repair or replace if over

**Cylindricity:** 0.05mm repair or replace if over



**Service Limit:**

A close-up photograph of the rear suspension assembly of a vehicle. The image shows the shock absorbers, springs, and a white cloth covering a component. The suspension is mounted on a metal frame, and a chain is visible in the background.

\*


- 
- Diagram illustrating the exploded view of a 120mm diameter oil ring assembly. The components are labeled as follows:
- Top
  - Second
  - Side Rail
  - Oil Ring
  - Side Rail
- Dimensions shown:
- Top rail diameter: 120°
  - Top rail thickness: 20 mm
  - Side Rail diameter: 120 mm

## 8. CYLINDER/PISTON

### PISTON INSTALLATION


Remove any gasket material from the crankcase surface.

- \* Be careful not to drop foreign matters into the crankcase.



Install the piston, piston pin and a new piston pin clip.

- \*
  - Position the piston "IN" mark on the intake valve side.
  - Place a clean shop towel in the crankcase to keep the piston pin clip from falling into the crankcase.



Piston Pin Clip

Piston Pin

Piston

### CYLINDER INSTALLATION


Install the dowel pins and a new cylinder gasket on the crankcase.



Gasket

Coat the cylinder bore, piston and piston rings with clean engine oil. Carefully lower the cylinder over the piston by compressing the piston rings.


- \*
  - Be careful not to damage or break the piston rings.
  - Stagger the ring end gaps at 120° to the piston pin.



Cylinder

## 8. CYLINDER/PISTON

Loosely install the cylinder base bolts.



Cam Chain Guide

Install the cam chain guide.

- \* Insert the tab on the cam chain guide into the cylinder groove.

Install the cylinder head.  
Tighten the cylinder base bolts.



Cylinder Base Bolt



## Super 8 50



|                            |     |                            |     |
|----------------------------|-----|----------------------------|-----|
| SERVICE INFORMATION .....  | 9-1 | DRIVE BELT .....           | 9-5 |
| TROUBLESHOOTING .....      | 9-1 | DRIVE PULLEY .....         | 9-6 |
| LEFT CRANKCASE COVER ..... | 9-2 | CLUTCH/DRIVEN PULLEY ..... | 9-9 |
| KICK STARTER .....         | 9-2 |                            |     |

### SERVICE INFORMATION

#### GENERAL INSTRUCTIONS

- The drive pulley, clutch and driven pulley can be serviced with the engine installed.
- Avoid getting grease and oil on the drive belt and pulley faces. Remove any oil or grease from them to minimize the slipping of drive belt and drive pulley.

#### SPECIFICATIONS

| Item                            | Standard (mm) | Service Limit (mm) |
|---------------------------------|---------------|--------------------|
| Movable drive face bushing I.D. | 23.989~24.025 | 24.06              |
| Drive face collar O.D.          | 23.960~23.974 | 23.94              |
| Drive belt width                | 17.5          | 16.5               |
| Clutch lining thickness         | —             | 1.5                |
| Clutch outer I.D.               | 107.0-107.2   | 107.5              |
| Driven face spring free length  | —             | 97                 |
| Driven face O.D.                | 33.965-33.485 | 33.94              |
| Movable driven face I.D.        | 34.0-34.025   | 34.06              |
| Weight roller O.D.              | 15.920~16.080 | 15.4               |

#### TORQUE VALUES

|                        |              |
|------------------------|--------------|
| Drive face nut         | 5.5~6.5kgf-m |
| Clutch outer nut       | 3.5~4.5kgf-m |
| Clutch drive plate nut | 5.0-6.0kg-m  |

#### SPECIAL TOOLS

Universal holder

Clutch spring compressor

### TROUBLESHOOTING

#### Engine starts but motorcycle won't move

- Worn drive belt
- Broken ramp plate
- Worn or damaged clutch lining
- Broken driven face spring

#### Engine stalls or motorcycle creeps

- Broken clutch weight spring

#### Lack of power

- Worn drive belt
- Weak driven face spring
- Worn weight roller
- Fouled drive face

### LEFT CRANKCASE COVER

#### REMOVAL


Loosen the drive belt air tube band screw.

Air Tube Band



Remove the left crankcase cover bolts.  
Remove the seal rubber and dowel pins.

Left Crankcase Cover




#### INSTALLATION

Install the dowel pins and gasket.


Bolts

Dowel Pins



Install the left crankcase cover and tighten  
the left crankcase cover bolts.  
Install the cable clamp to the specified  
location and tighten the bolt.

Left Crankcase Cover



Bolts

Install the drive belt air tube and tighten the  
tube band screw.


### DRIVE PULLEY

#### REMOVAL

Remove the left crankcase cover.  
Hold the drive pulley using an universal holder and remove the drive face nut and starting ratchet.  
Remove the drive pulley face.


Special

Flywheel Holder



Hold the clutch outer with the universal holder and remove the clutch outer nut.  
Remove the clutch/driven pulley and drive belt.

#### Movable Drive Face




#### INSPECTION

Check the drive belt for cracks, separation or abnormal or excessive wear.  
Measure the drive belt width.

**Service Limit:** 17.0mm replace if below

\* Use specified genuine parts for replacement.




Remove the movable drive face assembly.  
Remove the drive pulley collar.

## 9. DRIVE AND DRIVEN PULLEYS

### DISASSEMBLY

Remove the ramp plate.

Drive Pulley Collar



Movable Drive Face Assembly

Remove the weight rollers.

Ramp Plate



### INSPECTION


Check each weight roller for wear or damage.

Measure each weight roller O.D.

**Service Limit:** 15.4mm replace if below



Weight Roller



## 9. DRIVE AND DRIVEN PULLEYS


Measure the movable drive face bushing I.D.

**Service Limit:** 24.06mm replace if over




Check the drive pulley collar for wear or damage.  
Measure the O.D. of the drive pulley collar sliding surface.

**Service Limit:** 19.97mm replace if below




### ASSEMBLY

Install the weight rollers into the movable drive face.



Weight Roller


Install the ramp plate.



Ramp Plate


## 9. DRIVE AND DRIVEN PULLEYS

Insert the drive pulley collar into the movable drive face.




### INSTALLATION

Install the movable drive face onto the crankshaft.



Lay the drive belt on the driven pulley.  
Set the drive belt on the drive pulley collar.




## 9. DRIVE AND DRIVEN PULLEYS

Install the drive pulley face, starting ratchet and drive face nut.

- \* When installing the drive pulley face, compress it to let the drive belt move downward to the lowest position so that the drive pulley can be tightened.
- Install the starting ratchet by aligning the starting ratchet teeth with the crankshaft teeth.

Drive Pulley Face



Hold the drive pulley with the universal holder and tighten the drive face nut.


**Torque:** 5.5kg-m

Special

Flywheel Holder

- \* Do not get oil or grease on the drive belt or pulley faces.

Drive Pulley



Clutch Outer


Flywheel Holder Drive Face Nut

### CLUTCH/DRIVEN PULLEY

Remove the left crankcase cover.  
Remove the drive pulley and drive belt.  
Hold the clutch outer with the universal holder and remove the clutch outer nut.

Special

Flywheel Holder



Flywheel Holder

### INSPECTION

Inspect the clutch outer for wear or damage.  
Measure the clutch outer I.D.

**Service Limit:** 125.5mm replace if over



Check the clutch shoes for wear or damage.




## 9. DRIVE AND DRIVEN PULLEYS


Measure the clutch lining thickness.

**Service Limit:** 1.5mm replace if below

### CLUTCH/DRIVEN PULLEY DISASSEMBLY



Clutch/Driven Pulley




Hold the clutch/driven pulley assembly with the clutch spring compressor.

\* Be sure to use a clutch spring compressor to avoid spring damage.

Special

Clutch Spring Compressor

Clutch Spring Compressor



Set the clutch spring compressor in a vise and remove the clutch drive plate nut.



Loosen the clutch spring compressor and disassemble the clutch/driven pulley assembly.  
Remove the seal collar.



## 9. DRIVE AND DRIVEN PULLEYS

Pull out the guide roller pins and guide rollers. Remove the movable driven face from the driven face.


Remove the oil seal from the movable driven face.



### INSPECTION


Measure the driven face spring free length.

**Service Limit:** 97mm replace if below



Check the driven face for wear or damage. Measure the driven face O.D.


**Service Limit:** 33.94mm replace if below



Check the movable driven face for wear or damage.

Measure the movable driven face I.D.

**Service Limit:** 34.06mm replace if over



### DRIVEN PULLEY FACE BEARING REPLACEMENT

Drive the inner needle bearing out of the driven pulley face.

- \* Discard the removed bearing and replace with a new one.




Inner Bearing

Remove the drive the outer bearing out of the driven face.

- \* Discard the removed bearing and replace with a new one.

Apply grease to the outer bearing.  
Drive a new outer bearing into the driven face with the sealed end facing up.



Outer Bearing

Apply grease to the driven face bore areas.

- \* Pack all bearing cavities with 5.0~5.6g grease.  
Specified grease: Heat resistance 230°C




Press a new needle bearing into the driven face.



### CLUTCH DISASSEMBLY


Remove the circlips and retainer plate to disassemble the clutch.

\* Keep grease off the clutch linings.




### CLUTCH ASSEMBLY

Install the damper rubbers on the drive plate pins.  
Install the clutch weights/shoes and clutch springs onto the drive plate.  
Install the retainer plate and secure with the circlips.



### CLUTCH/DRIVEN PULLEY ASSEMBLY

Clean the driven pulley faces and remove any grease from them.  
Install the oil seal onto the moveable driven face.  
Apply grease to the O-rings and install them onto the moveable driven face.



## 9. DRIVE AND DRIVEN PULLEYS

Install the movable driven face onto the driven face.

Apply grease to the guide rollers and guide roller pins and then install them into the holes of the driven face.

Install the seal collar.

Remove any excessive grease.

- \* Be sure to clean the driven face off any grease.

Set the driven pulley assembly, driven face spring and clutch assembly onto the clutch spring compressor.

- \* Align the flat surface of the driven face with the flat on the clutch drive plate.

Compress the clutch spring compressor and install the drive plate nut.

Set the clutch spring compressor in a vise and tighten the drive plate nut to the specified torque.

**Torque:** 5.5kg-m

- \* Be sure to use a clutch spring compressor to avoid spring damage.




Special

Clutch Spring Compressor

### INSTALLATION

Install the clutch/driven pulley onto the drive shaft.

- \* Keep grease off the drive shaft.



## 9. DRIVE AND DRIVEN PULLEYS

---

### Clutch/Driven Pulley

Install the clutch outer.  
Hold the clutch outer with the universal  
holder.

Install and tighten the clutch outer nut.


**Torque:** 5.5kg-m

Special


Flywheel Holder

Install the drive belt.

Install the left crankcase cover.



## 10. FINAL REDUCTION



# 10. FINAL REDUCTION

---

|                                      |                                       |
|--------------------------------------|---------------------------------------|
| SERVICE INFORMATION .....10-1        | FINAL REDUCTION INSPECTION ..... 10-2 |
| TROUBLESHOOTING .....10-1            | BEARING REPLACEMENT ..... 10-3        |
| FINAL REDUCTION DISASSEMBLY ....10-2 | FINAL REDUCTION ASSEMBLY ..... 10-4   |

## SERVICE INFORMATION

### SPECIFICATIONS

Specified Oil: GEAR OIL SAE 90#

Oil Capacity:       At disassembly : 0.21   liter  
                           At change         : 0.18 liter

### SPECIAL TOOLS

Bearing puller, 10,12,15,18mm

**10**

## TROUBLESHOOTING

### Engine starts but motorcycle won't move

- Damaged transmission
- Seized or burnt transmission
- Faulty drive belt
- Faulty clutch

### Abnormal noise

- Worn, seized or chipped gears
- Worn bearing

### Oil leaks


- Oil level too high
- Worn or damaged oil seal




## 10. FINAL REDUCTION

### FINAL REDUCTION DISASSEMBLY

Remove the rear brake cable. (⇒13-3)  
 Remove the rear wheel. (⇒13-2)  
 Remove the left crankcase cover. (⇒9-2)  
 Remove the clutch/driven pulley. (⇒9-10)  
 Drain the transmission gear oil into a clean container.  
 Remove the transmission case cover attaching bolts.  
 Remove the transmission case cover.  
 Remove the gasket and dowel pins.




Remove the final gear and countershaft.




### FINAL REDUCTION INSPECTION

Inspect the countershaft and gear for wear or damage.




Inspect the final gear and final shaft for wear, damage or seizure.




## 10. FINAL REDUCTION

Check the left crankcase bearings for excessive play and inspect the oil seal for wear or damage.



Inspect the drive shaft and gear for wear or damage.  
Check the transmission case cover bearings for excessive play and inspect the final shaft bearing oil seal for wear or damage.

\* Do not remove the transmission case cover except for necessary part replacement. When replacing the drive shaft, also replace the bearing and




### BEARING REPLACEMENT (TRANSMISSION CASE COVER)


Remove the transmission case cover bearings using a bearing puller.  
Remove the final shaft oil seal.

Special

Bearing Puller



Drive new bearings into the transmission case cover.



Outer Driver, 32x35mm


## 10. FINAL REDUCTION

### BEARING REPLACEMENT (LEFT CRANKCASE)

Remove the drive shaft.  
Remove the drive shaft oil seal.  
Remove the left crankcase bearings using a bearing puller.


**Special**

Bearing Puller



Bearing Puller, 12mm


Drive new bearings into the left crankcase.  
Install a new drive shaft oil seal.



Pilot


### FINAL REDUCTION ASSEMBLY

Install the drive shaft into the left crankcase.




Drive Shaft

Install the final gear and final shaft into the left crankcase.




## 10. FINAL REDUCTION

Install the countershaft and gear into the left crankcase.  
Install the dowel pins and a new gasket.




Install the transmission case cover.



Transmission Case Cover  
Bolts

Install and tighten the transmission case cover bolts.  
Install the clutch/driven pulley. (⇒9-13)



After installation, fill the transmission case with the specified oil. (⇒3-7)

**\***

- Place the motorcycle on its main stand on level ground.
- Check the oil sealing washer for wear or damage.

**Specified Gear Oil:** SAE90#

**Oil Capacity:**


At disassembly : 0.2 liter

At change : 0.18 liter


Install and tighten the oil check bolt.

**Torque:** 0.8~1.2kgf-m

Start the engine and check for oil leaks.  
Check the oil level from the oil check bolt hole and add the specified oil to the proper level if the oil level is low.



# 11. CRANKCASE/CRANKSHAFT



# 11. CRANKCASE/CRANKSHAFT

|                            |      |                         |      |
|----------------------------|------|-------------------------|------|
| SERVICE INFORMATION.....   | 11-1 | CRANKSHAFT.....         | 11-3 |
| TROUBLESHOOTING.....       | 11-1 | CRANKCASE ASSEMBLY..... | 11-4 |
| CRANKCASE SEPARATION ..... | 11-2 |                         |      |

## SERVICE INFORMATION

### GENERAL INSTRUCTIONS

- This section covers crankcase separation to service the crankshaft. The engine must be removed for this operation.
- The following parts must be removed before separating the crankcase.
  - Cylinder head (⇒Section 7)
  - Cylinder/piston (⇒Section 8)
  - Drive and driven pulleys (⇒Section 9)
  - A.C. generator (⇒Section 14)
  - Carburetor/air cleaner (⇒Section 5)
  - Rear wheel/rear shock absorber (⇒Section 13)
  - Starter motor (⇒Section 16)
  - Oil pump (⇒Section 4)

### SPECIFICATIONS

|            | Item                                    | Standard (mm) | Service Limit (mm) |
|------------|-----------------------------------------|---------------|--------------------|
| Crankshaft | Connecting rod big end side clearance   | 0.10~0.35     | 0.55               |
|            | Connecting rod big end radial clearance | 0-0.008       | 0.05               |
|            | Runout                                  | —             | 0.10               |

### TORQUE VALUES

|                                  |              |
|----------------------------------|--------------|
| Crankcase bolt                   | 0.8~1.2kgf-m |
| Cam chain tensioner slipper bolt | 0.8~1.2kgf-m |

## TROUBLESHOOTING

### Excessive engine noise


- Excessive bearing play
- Excessive crankpin bearing play

## 11. CRANKCASE/CRANKSHAFT


### CRANKCASE SEPARATION

Remove the two crankcase attaching bolts.  
Separate the left and right crankcase halves.


\* Do not damage the crankcase gasket surface.



Remove the gasket and dowel pins.




Remove the crankshaft and cam chain from the left crankcase.




Clean off all gasket material from the crankcase mating surfaces.

\* Avoid damaging the crankcase mating surfaces.



## 11. CRANKCASE/CRANKSHAFT

Remove the oil seal from the right crankcase.  
Check the oil seal lip for wear or deterioration.  
The installation sequence is the reverse of removal.



### CRANKSHAFT INSPECTION

Measure the connecting rod big end side clearance.


**Service Limit:** 0.55mm replace if over



Connecting Rod Big End

Measure the connecting rod big end radial clearance at two points at right angles to the shaft.


**Service Limit:** 0.05mm replace if over



Measuring Location

Measure the crankshaft runout.


**Service Limit:** 0.10mm replace if over






## 11. CRANKCASE/CRANKSHAFT

Turn the crankshaft bearings and check for excessive play.  
If they do not turn smoothly, quietly or if they fit loosely in the crankshaft, replace the crankshaft as a set.



### CRANKCASE ASSEMBLY

Install the cam chain into the left crankcase.



Cam Chain


Install the crankshaft into the left crankcase.



Install the dowel pins and a new gasket onto the left crankcase.

\* Place the right crankcase over the crankshaft and onto the left crankcase.

Gasket




Dowel Pins

## 11. CRANKCASE/CRANKSHAFT

---

Tighten the two crankcase attaching bolts.

**Torque:** 0.8~1.2kg-m



**KYMCO**  
**SUPER 8 50**



## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

|                           |      |                           |       |
|---------------------------|------|---------------------------|-------|
| SERVICE INFORMATION ..... | 12-1 | FRONT SHOCK ABSORBER..... | 12-18 |
| TROUBLESHOOTING .....     | 12-2 | FRONT FORK.....           | 12-21 |
| STEERING HANDLEBAR .....  | 12-3 |                           |       |
| FRONT WHEEL.....          | 12-4 |                           |       |

### SERVICE INFORMATION

#### GENERAL INSTRUCTIONS

- Remove the motorcycle frame covers before removing the front wheel. Jack the motorcycle front wheel off the ground and be careful to prevent the motorcycle from falling down.
- During servicing, keep oil or grease off the brake drum and brake linings.

#### SPECIFICATIONS

| Item                                    |        | Standard (mm) | Service Limit (mm) |
|-----------------------------------------|--------|---------------|--------------------|
| Axle shaft runout                       |        | —             | 0.2                |
| Front wheel rim runout                  | Radial | —             | 2.0                |
|                                         | Axial  | —             | 2.0                |
| Front shock absorber spring free length |        | 230           | 226.5              |
|                                         |        |               |                    |
|                                         |        |               |                    |

#### TORQUE VALUES

|                           |              |
|---------------------------|--------------|
| Handlebar bolt            | 4.5~5.5kgf-m |
| Steering stem lock nut    | 6.0~8.0kgf-m |
| Steering top cone race    | 0.5~1.3kgf-m |
| Front shock absorber bolt | 3.0kgf-m     |
| Front axle nut            | 5.0~7.0kgf-m |
| Brake arm bolt            | 0.8~1.2kgf-m |

#### SPECIAL TOOLS

Long socket wrench, 32mm 8angle

### TROUBLESHOOTING

#### **Hard steering (heavy)**

- Excessively tightened steering stem top cone race
- Broken steering balls
- Insufficient tire pressure

#### **Steers to one side or does not track straight**

- Uneven front shock absorbers
- Bent front fork
- Bent front axle or uneven tire

#### **Front wheel wobbling**

- Bent rim
- Excessive wheel bearing play
- Bent spoke plate
- Faulty tire
- Improperly tightened axle nut

#### **Soft front shock absorber**

- Weak shock springs
- Insufficient damper oil

#### **Front shock absorber noise**

- Slider bending
- Loose fork fasteners
- Lack of lubrication

## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

### STEERING HANDLEBAR

#### REMOVAL

Remove the handlebar front and rear covers.  
(⇒2-2)

Remove the two bolts attaching each of the  
front and rear brake levers.

Remove the front and rear brake levers.




Bolts

Bolts

Remove the two throttle holder screws and  
throttle holder.

Disconnect the throttle cable from the throttle  
pipe and then remove the throttle pipe from  
the handlebar.




Screws

Throttle Pipe

Throttle Cable

Remove the handlebar lock nut and bolt to  
remove the handlebar.



Nut


Bolt

#### INSTALLATION

Install the handlebar onto the steering stem by  
aligning the tab on the handlebar with the bolt  
orifice on the steering stem.

Install and tighten the handlebar bolt and lock  
nut.


**Torque:** 4.5~5.5kgf-m




Bolt Orifice

## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

Apply grease to the tip of the throttle pipe.  
Install the throttle pipe and connect the  
throttle cable.




Install the front and rear brake levers in the  
reverse order of removal.



### FRONT WHEEL

#### REMOVAL

Jack the motorcycle front wheel off the  
ground.  
Remove the speedometer cable set screw and  
disconnect the speedometer cable.  
Remove the front axle nut and pull out the  
axle.  
Remove the front wheel.  
Remove the and speedometer gear box and  
side collar.




#### INSPECTION

##### AXLE RUNOUT

Set the axle in V blocks and measure the  
runout using a dial gauge.  
The actual runout is  $\frac{1}{2}$  of the total indicator  
reading.

**Service Limit:** 0.2mm replace if over



## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION


### WHEEL RIM

Check the wheel rim runout.


#### Service Limits:

**Radial:** 2.0mm replace if over

**Axial:** 2.0mm replace if over



Turn the wheel bearings and replace the bearings if they are noisy or have excessive play.



### DISASSEMBLY

Remove the dust seal.



Remove the front wheel bearings and distance collar.

**Special**


Bearing Puller






## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

### ASSEMBLY




Pack all bearing cavities with grease.  
Drive in the left bearing.  
Install the distance collar.  
Drive in the right bearing.

\* Drive in the bearing squarely with the sealed end facing out.



Outer Driver Pilot

Apply grease to a new dust seal lip and install the dust seal.  
Install the side collar.



Dust Seal

## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

### HYDRAULIC BRAKE (FRONT BRAKE)


Brake Fluid Replacement/Air Bleeding

Check the brake fluid level on level ground.

**\***

- When operating the brake lever, the brake reservoir cap must be tightened securely to avoid spill of brake fluid.
- When servicing the brake system, use shop towels to cover plastic parts and coated surfaces to avoid damage caused by spill of brake fluid.

Upper Limit



Lower Limit

### Brake Fluid Bleeding


In order to avoid spill of brake fluid, connect a transparent hose to the bleed valve.

#### Warning

Brake fluid spilled on brake pads or brake disk will reduce the braking effect. Clean the brake pads and brake disk with a high quality brake degreaser.

Fully apply the brake lever and then loosen the brake caliper bleed valve to drain the brake fluid until there is no air bubbles in the brake fluid. Then, tighten the bleed valve. Repeat these steps until the brake system is free of air.

Bleed Valve



Front Brake Caliper

### Brake Fluid Refilling

Add DOT-4 brake fluid to the brake reservoir.

**\***

- When bleeding, be careful not to allow air in the brake reservoir flowing into the brake system.
- When using a brake bleeder, follow the manufacturer's instructions.
- Never use dirty or unspecified brake fluid or mix different brake fluids because it will damage the brake

Make sure to bleed air from the brake system.

## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

### Brake Pad/Disk Replacement




The brake pads must be replaced as a set to ensure the balance of the brake disk.

Remove the two bolts attaching the brake caliper.  
Remove the brake caliper.  
Downpress reed and remove the brake pads.  
Install the brake pads in the reverse order of removal.



- Keep grease or oil off the brake pads to avoid brake failure.



### Brake Disk

Measure the brake disk thickness.

**Service Limit:** 3.0mm

Measure the brake disk runout.

**Service Limit:** 0.3mm



## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION


### BRAKE MASTER CYLINDER

#### Removal

First drain the brake fluid from the hydraulic brake system.


\*

- When servicing the brake system, use shop towels to cover rubber and plastic parts and coated surfaces to avoid being contaminated by brake fluid.
- When removing the brake fluid pipe bolt, be sure to plug the pipe to avoid brake fluid leakage.




#### Disassembly

Remove the piston rubber cover and snap ring from the brake master cylinder.



Remove the washer, main piston and spring from the brake master cylinder.  
Clean the inside of the master cylinder and brake reservoir with brake fluid.




## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

### Inspection

Measure the brake master cylinder I.D.

**Service Limit:** 12.75mm

Inspect the master cylinder for scratch or crack.



Measure the brake master cylinder piston O.D.

**Service Limit:** 12.6mm

Before assembly, inspect the 1st and 2nd rubber cups for wear.



### Assembly

Before assembly, apply brake fluid to all removed parts.

Install the spring together with the 1st rubber cup.

**\***

- During assembly, the main piston and spring must be installed as a unit without exchange.
- When assembling the piston, soak the cups in brake fluid for a while.
- Install the cups with the cup lips facing the correct direction.



Install the main piston, spring and snap ring.

Install the rubber cover.


Install the brake lever.

## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

### Disassembly

Remove the brake caliper seat from the brake caliper.

Brake Caliper Seat



Remove the piston from the brake caliper. If necessary, use compressed air to squeeze out the piston through the brake fluid inlet opening and place a shop towel under the caliper to avoid contamination caused by the removed piston. Check the piston cylinder for scratch or wear and replace if necessary.

Compressed Air




Push the piston oil seal outward to remove it. Clean the oil seal groove with brake fluid.

**\***

Be careful not to damage the piston surface.


Piston Oil Seal



## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION


Place the brake master cylinder on the handlebar and install the holder with “up” mark facing up. Be sure to align the punch mark with the holder joint. First tighten the upper bolt and then tighten the lower bolt.

**Torque:** 3.0~4.0kgf-m



Install the brake fluid pipe with the attaching bolt and two sealing washers.

Install the handlebar covers. (⇒12-3)  
Fill the brake reservoir with recommended brake fluid to the upper limit and bleed air according to the method stated in 12-10.



Brake Caliper

Bleed Valve


### BRAKE CALIPER (FRONT)

#### Removal

Remove the brake caliper.  
Place a clean container under the brake caliper and disconnect the brake fluid pipe from the caliper.



Do not spill brake fluid on any coated surfaces.



Bolt

Bleed Valve

## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

Check the piston for scratch or wear.  
Measure the piston O.D. with a micrometer.  
**Service Limit:** 34mm



Check the caliper cylinder for scratch or wear  
and measure the cylinder bore.  
**Service Limit:** 34.5mm



### Assembly

Clean all removed parts.  
Apply silicon grease to the piston and oil seal.  
Lubricate the brake caliper cylinder inside  
wall with brake fluid.  
Install the brake caliper piston with grooved  
side facing out.

**\***

Install the piston with its outer end 3~  
5mm protruding beyond the brake  
caliper.

Wipe off excessive brake fluid with a clean  
shop towel. Apply silicon grease to the  
brake caliper seat pin and caliper inside.  
Install the brake caliper seat.






## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

### Installation

Install the brake caliper and tighten the two bolts.

**Torque:** 2.9~3.5kg-m



Bolts

Connect the brake fluid pipe to the brake caliper and tighten the fluid pipe bolt.

**Torque:** 2.5~3.5kg-m

Fill the brake reservoir with recommended brake fluid and bleed air from the brake system. (⇒12-10)



Bolt

## 12. FRONT WHEEL/Front BRAKE/ FRONT SUSPENSION

### FRONT SHOCK ABSORBER

#### REMOVAL

Remove the front wheel. (⇒12-4)  
Remove the front lower cover. (⇒2-2)  
Remove the front inner fender.  
Remove the front shock absorber upper  
mount bolts.  
Loosen the lower mount bolts to remove the  
front shock absorbers.

#### DISASSEMBLY

Remove the dust boot.  
Remove the circlip.


Set the front shock absorber in a vise.  
Remove the damper rod, hex bolt and copper  
washer.  
Pull out the front shock absorber tube.

Set the front shock absorber tube in a vise.  
Remove the top nut, shock spring, damper,  
and damper spring from the front shock  
absorber tube.

**\***


- When holding the shock absorber tube,  
place a shop towel to protect it and do  
apply too much force .

Upper Mount Bolts



Shock Absorber

Lower Mount Bolts  
Circlip



Dust Boot



Washer/Bolt

Front Shock Absorber


Shock Absorber Tube




## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

Measure the front shock absorber spring free length.

**Service Limits:** Right : 226.5mm  
Left : 226.5mm



### ASSEMBLY



Install the damper spring onto the damper rod  
and then install them into the front shock

## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

absorber tube.

Install the shock absorber spring onto the front shock absorber tube and tighten the top nut.

- \* Install the front shock absorber spring with the closely wound coils facing down.

Set the front shock absorber in a vise.

Insert the shock absorber tube into the shock absorber and tighten the hex bolt.

(Apply locking agent to the washer and install it together with the hex bolt.)

**Torque:** 3.0kgf-m


Add engine oil into the front shock absorber.

**Specified Oil:** SS#8


**Oil Capacity:** 97±1cc

Install the circlip.

Install the dust boot.



Shock Absorber Tube  
Circlip



Dust Boot

Upper Mount Bolts



Front Shock Absorber

Lower Mount Bolts

### INSTALLATION

Install the front shock absorbers onto the steering stem.

Install and tighten the front shock absorber upper mount bolts.

Tighten the lower mount bolts.

- \* Align the upper mount bolt hole with the groove on the front fork.

Install the front wheel. (⇒12-7)

## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

### FRONT FORK

#### REMOVAL

Remove the steering handlebar. (⇒12-3)  
Remove the front wheel. (⇒12-4)  
Disconnect the speedometer cable.  
Remove the steering stem lock nut using long socket wrench.

**Special**

Long Socket Wrench, 32mm 8Angle

Remove the top cone race and remove the steering stem.

\*

- Be careful not to lose the steel balls (26 on top race and 29 on bottom race).

Inspect the ball races and cone races for wear or damage and replace if necessary.

#### BOTTOM CONE RACE REPLACEMENT

Remove the bottom cone race using a chisel.

\*


- Be careful not to damage the steering stem and front fork.

Drive a new bottom cone race into place with a proper driver.


#### BALL RACE REPLACEMENT

Drive out the top and bottom ball races.


Long Socket Wrench



Lock Nut Wrench




Top Cone Race



Bottom Cone Race

Ball Race Remover



## 12. FRONT WHEEL/FRONT BRAKE/ FRONT SUSPENSION

Drive new top and bottom ball races into the steering head using the outer driver.



Be sure to completely drive in the ball races.

### INSTALLATION

Apply grease to the top and bottom ball races and install 26 steel balls on the top ball race and 29 steel balls on the bottom ball race. Apply grease to the ball races and install the front fork.

Apply grease to the top cone race and install it.

Tighten the top cone race and then turn the steering stem right and left several times to make steel balls contact each other closely.



Check that the steering stem rotates freely without vertical play.

Install the steering stem lock nut and tighten it while holding the top cone race.

**Torque:** 6.0~8.0kgf-m

Install the front wheel. (⇒12-7)


Install the steering handlebar. (⇒12-3)

Install the speedometer cable. (⇒12-7)

**Special**

Long Socket Wrench, 32mm × 8 Angle

Driver Handle A




Outer Driver, 37x40mm



Steel Balls

Top Cone Race



Long Socket Wrench



Lock Nut Wrench

**13. REAR WHEEL/REAR BRAKE/REAR  
SHOCK ABSORBER**

---



**SUPER 8 50**

---

**REAR WHEEL/REAR BRAKE/REAR  
SHOCK ABSORBER**

---

SERVICE INFORMATION ..... 13-2

TROUBLESHOOTING ..... 13-2



REAR BRAKE..... 13-3

REAR WHEEL -----13-7

REAR SHOCK ABSORBER ..... 13-8

## 13. REAR WHEEL/REAR BRAKE/REAR SHOCK ABSORBER

---





# 13. REAR WHEEL/REAR BRAKE/REAR SHOCK ABSORBER

SUPER 8 50

## SERVICE INFORMATION

### GENERAL INSTRUCTIONS

\*When performing the service stated in this section, the engine and exhaust muffler must be cold to avoid scalding.

\*During servicing, keep oil or grease off the brake pads and brake disk.

### REAR SHOCK ABSORBER REMOVAL

Remove the met-in box.

Remove the frame body cover

Remove the suspension upper mount bolt

Remove the suspension lower mount bolt

Remove the rear shock absorber



### INSTALLATION

Install the upper and lower mount bolts.

Install the frame body cover.

#### Torque:

**Upper Mount Bolt:** 35~45Nm

**Lower Mount Bolt:** 24~30Nm



### REAR WHEEL REMOVAL

Disconnect the connector of O<sub>2</sub> sensor.

Remove the muffler mount bolts

Remove the muffler.

Remove the rear fork

Remove the rear axle mount bolt

Remove the rear wheel.



rear fork

### INSTALLATION

Install the rear wheel in reverse order of removal.

#### Torque:

**Rear axle Mount Bolt:** 110~130Nm

**Muffler Mount Bolts:** 35 Nm

**Muffler Joint Bolts:** 12Nm

## 13. REAR WHEEL/REAR BRAKE/REAR SHOCK ABSORBER


### REAR BRAKE REMOVAL

#### BRAKE LINING INSPECTION

Measure the brake lining thickness.

**Service Limit:** 2.0mm replace if below


\* Keep oil or grease off the brake linings.



### REAR BRAKE DISASSEMBLY


Remove the rear brake adjusting nut and disconnect the rear brake cable.

Remove the rear brake shoes.



Remove the brake arm bolt to remove the brake arm.

Remove the brake cam.




Brake Arm  
Grease

### REAR BRAKE ASSEMBLY

Apply grease to the anchor pin.

Apply grease to the brake cam and install it.

Install the brake shoes.



## 13. REAR WHEEL/REAR BRAKE/REAR SHOCK ABSORBER

SUPER 8 50


Apply a small amount of engine oil to the felt seal and install it to the brake cam.  
Install the brake arm.

- \* Align the wide groove on the wear indicator plate with the wide tooth of the brake cam.

Install and tighten the brake arm bolt.


- \* Align the scribed line on the brake arm with the punch mark on the brake cam.

Install the brake arm return spring.  
Install the brake arm pin.  
Connect the brake cable and install the adjusting nut.  
Install the rear wheel. (⇒13-2)  
Adjust the rear brake lever free play. (⇒3-8)





Return Spring  
Brake Cable

Brake Arm  
Brake Arm



Adjusting Nut

## 14. BATTERY/CHARGING SYSTEM/ A.C. GENERATOR





## 14. BATTERY/CHARGING SYSTEM/ A.C. GENERATOR

|                          |      |                                   |      |
|--------------------------|------|-----------------------------------|------|
| SERVICE INFORMATION..... | 14-1 | A.C. GENERATOR CHARGING COIL .... | 14-6 |
| TROUBLESHOOTING.....     | 14-2 | RESISTOR INSPECTION.....          | 14-6 |
| BATTERY .....            | 14-3 | A.C. GENERATOR REMOVAL .....      | 14-6 |
| CHARGING SYSTEM .....    | 14-4 | A.C. GENERATOR INATALLATION....   | 14-8 |
| REGULATOR/RECTIFIER..... | 14-5 |                                   |      |

### SERVICE INFORMATION

#### GENERAL INSTRUCTIONS



The battery electrolyte (sulfuric acid) is poisonous and may seriously damage the skin and eyes. Avoid contact with skin, eyes, or clothing. In case of contact, flush with water and get prompt medical attention

- The battery can be charged and discharged repeatedly. If a discharged battery is not used for a long time, its service life will be shortened. Generally, the capacity of a battery will decrease after it is used for 2~3 years. A capacity-decreased battery will resume its voltage after it is recharged but its voltage decreases suddenly and then increases when a load is added.
- When a battery is overcharged, some symptoms can be found. If there is a short circuit inside the battery, no voltage is produced on the battery terminals. If the rectifier won't operate, the voltage will become too high and shorten the battery service life.
- If a battery is not used for a long time, it will discharge by itself and should be recharged every 3 months.
- A new battery filled with electrolyte will generate voltage within a certain time and it should be recharged when the capacity is insufficient. Recharging a new battery will prolong its service life.
- Inspect the charging system according to the sequence specified in the Troubleshooting.
- Do not disconnect and soon reconnect the power of any electrical equipment because the electronic parts in the regulator/rectifier will be damaged. Turn off the ignition switch before operation.
- It is not necessary to check the MF battery electrolyte or fill with distilled water.
- Check the load of the whole charging system.
- Do not quick charge the battery. Quick charging should only be done in an emergency.
- Remove the battery from the motorcycle for charging.
- When replacing the battery, do not use a traditional battery.
- When charging, check the voltage with an voltmeter.

## 14. BATTERY/CHARGING SYSTEM/ A.C. GENERATOR

### SPECIFICATIONS

| Item                |                   |               | Standard                    |
|---------------------|-------------------|---------------|-----------------------------|
| Battery             | Capacity/Model    |               | 12V-8AH                     |
|                     | Voltage<br>(20°C) | Fully charged | 13.1V                       |
|                     |                   | Undercharged  | 12.3V                       |
|                     | Charging current  |               | STD: 0.4A    Quick: 4.0A    |
|                     | Charging time     |               | STD: 5~10hr    Quick: 30min |
| Regulator/Rectifier | Limit voltage     |               | 14±0.5V/5000rpm             |

### TORQUE VALUES

|                  |               |
|------------------|---------------|
| Pulser coil bolt | 0.45~0.6kgf-m |
| Stator bolt      | 0.8~1.2kgf-m  |
| Flywheel nut     | 3.5~4.5kgf-m  |
| Cooling fan bolt | 0.8~1.2kgf-m  |

### SPECIAL TOOLS

Universal holder  
Flywheel puller

### TESTING INSTRUMENTS

Kowa electric tester  
Sanwa electric tester

### TROUBLESHOOTING

#### No power

- Dead battery
- Disconnected battery cable
- Fuse burned out
- Faulty ignition switch

#### Low power

- Weak battery
- Loose battery connection
- Charging system failure
- Faulty regulator/rectifier

#### Intermittent power

- Loose battery cable connection
- Loose charging system connection
- Loose connection or short circuit in lighting system

#### Charging system failure

- Loose, broken or shorted wire or connector
- Faulty regulator/rectifier
- Faulty A.C. generator

# 14. BATTERY/CHARGING SYSTEM/ A.C. GENERATOR

## BATTERY

### REMOVAL

Remove the battery cover screws on the floor board.

Open the battery cover and remove the battery by removing the bolt and band.

First disconnect the battery negative (-) cable and then the positive (+) cable.

When disconnecting the battery positive (+) cable, do not touch the frame with tool; otherwise it will cause short circuit and sparks to fire the fuel.

The installation sequence is the reverse of removal.

First connect the positive (+) cable and the negative (-) cable to avoid short circuit.

### BATTERY VOLTAGE (OPEN CIRCUIT VOLTAGE) INSPECTION

Remove the floor board.

Open the battery cover and disconnect the battery cables.

Measure the voltage between the battery terminals.

Fully charged : 13.1V

Undercharged: 12.3V max.

\* Battery charging inspection must be performed with a voltmeter.

### CHARGING

Connect the charger positive (+) cable to the battery positive (+) terminal.

Connect the charger negative (-) cable to the battery negative (-) terminal.

• Keep flames and sparks away from a charging battery.  
• Turn power ON/OFF at the charger, not at the battery terminals to prevent sparks near the battery to avoid explosion.  
• Charge the battery according to the current specified on the battery.

\* • Quick charging should only be done in an emergency.  
• Measure the voltage 30 minutes after the battery is charged.

Charging current: Standard : 0.4A  
Quick : 4A

Charging time : Standard : 5~10 hours  
Quick : 30 minutes

After charging: Open circuit voltage: 12.8V min.

Note: The battery temperature should not exceed 45°C during charging.

Battery Cover





battery

negative (-) cable



positive (+) cable



### CHARGING SYSTEM

#### SHORT CIRCUIT TEST

Disconnect the ground wire from the battery and connect an ammeter across the battery negative (-) terminal and the ground wire. Turn the ignition switch OFF and check for short circuit.

\* Connect the electric tester positive (+) terminal to ground wire and the tester negative (-) terminal to the battery negative (-) terminal.

If any abnormality is found, check the ignition switch and wire harness for short circuit .

#### CURRENT TEST

This inspection must be performed with an electric tester when the battery is fully charged.

Warm up the engine for inspection.



Connect the electric tester across the battery terminals. Disconnect the fuse and connect an ammeter between the fuse terminals.

Attach a tachometer to the engine.

Start the engine and gradually increase the engine speed to measure the limit voltage and current.

**Limit Voltage/Current:** 13.5~14.5V/0.5A  
max. (5000rpm  
max.)

If the limit voltage is not within the specified range, check the regulator/rectifier. (⇒14-5)





## 14. BATTERY/CHARGING SYSTEM/ A.C. GENERATOR

### REGULATOR/RECTIFIER

#### INSPECTION

Remove the met-in box.

Remove the regulator/rectifier wire coupler.

Check the continuity between the wire terminals.

Normal Direction: Continuity

|    | (+)Probe | (-)Probe |
|----|----------|----------|
| I  | Yellow   | Green    |
| II | Red      | Yellow   |

Reverse Direction: No Continuity

|    | (+)Probe | (-)Probe |
|----|----------|----------|
| I  | Green    | Yellow   |
| II | Yellow   | Red      |





#### VOLTAGE REGULATION TEST

Connect a voltmeter across the battery terminals.

Start the engine and gradually increase the engine speed to 5000 rpm.

The battery terminal voltage should be within 13.5V~14.5V.



## 14. BATTERY/CHARGING SYSTEM/ A.C. GENERATOR

### A.C. GENERATOR CHARGING COIL

\*

The inspection of A.C. generator charging coil can be made with the engine installed.

#### A.C GENERATOR INSPECTION

This test can be made without removing the stator from the engine. Disconnect the yellow wire from the auto-bystarter.

Remove the met-in box.

Disconnect the A.C. generator connector.

Check the continuity between the yellow wires and ground.

There should be continuity between the yellow wires and on continuity between each yellow wire and ground.

#### Resistance:

|               |                |
|---------------|----------------|
| Yellow~Yellow | 1~2.5 $\Omega$ |
|---------------|----------------|



## 14. BATTERY/CHARGING SYSTEM/ A.C. GENERATOR

### A.C. GENERATOR

#### REMOVAL

Remove the right side cover. (⇒2-4)


Remove the four bolts attaching the cooling fan cover to remove the fan cover.

Remove the cooling fan by removing the four cooling fan attaching bolts.



Cooling Fan

Universal Holder



Hold the flywheel with an universal holder.  
Remove the flywheel nut.

**Special**

Universal Holder

Remove the A.C. generator flywheel using  
the flywheel puller.  
Remove the woodruff key.

**Special**

Flywheel Puller



Flywheel Puller


A.C. Generator Wire Connector




Remove the A.C. generator wire connector.

## 14. BATTERY/CHARGING SYSTEM/ A.C. GENERATOR

Remove the A.C. generator wire set plate.  
Remove the pulser coil bolts.  
Remove the A.C. generator wire rubber sleeve and pulser coil from the right crankcase.  
Remove the two bolts and A.C. generator stator.




### A.C. GENERATOR INSTALLATION



Install the A.C. generator stator and pulser coil onto the right crankcase.  
Tighten the stator and pulser coil bolts.

**Torques:** Pulser Coil : 0.45~0.6kgf-m  
Stator : 0.8~1.2kgf-m

Install the A.C. generator wire rubber sleeve and A.C. generator wire set plate.



## 14. BATTERY/CHARGING SYSTEM/ A.C. GENERATOR


Connect the A.C. generator wire connector.

A.C. Generator Wire Connector



Clean the taper hole in the flywheel off any burrs and dirt.  
Install the woodruff key in the crankshaft keyway.

Woodruff Key




Install the flywheel onto the crankshaft with the flywheel hole aligned with the crankshaft woodruff key.

\* The inside of the flywheel is magnetic.  
Make sure that there is no bolt or nut  
before installation.

Hold the flywheel with the universal holder  
and tighten the flywheel nut.

**Torque:** 3.5~4.5kgf-m

Universal Holder




**Special**

Universal Holder

Install the cooling fan.

**Torque:** 0.8~1.2kgf-m




Cooling Fan

## 14. BATTERY/CHARGING SYSTEM/ A.C. GENERATOR

---


**KYMCO**  
SUPER 8 50

Install the fan cover.  
Install the right side cover. (⇒2-4)



Fan Cover

## 15. IGNITION SYSTEM




15



# 15. IGNITION SYSTEM

## SERVICE INFORMATION



### GENERAL INSTRUCTIONS

- Some electrical components may be damaged if terminals or connectors are connected or disconnected while the ignition switch is "ON" and current is present.
- When servicing the ignition system, always follow the steps in the troubleshooting on page 17-2.
- The ignition timing cannot be adjusted since the ignition control module is already adjusted in factory.
- The ignition control module or ECU may be damaged if dropped or the connector is disconnected when the key is "ON", the excessive voltage may damage the ignition control module or ECU. Always turn off the ignition switch before servicing.
- A faulty ignition system is often related to poor connections. Check those connections before proceeding.
- Make sure the battery is adequately charged. Using the starter motor with weak battery results in a slower engine cranking speed as well as no spark at the spark plug.
- Use a spark plug of the correct heat range. Using spark plug with an incorrect heat range can damage the engine.



# 15. IGNITION SYSTEM

## SPECIFICATIONS

| Item                                       |               | Standard                                    |
|--------------------------------------------|---------------|---------------------------------------------|
| Spark plug                                 | Standard type | NGK CR7HSA                                  |
| Spark plug gap                             |               | 0.6 ~ 0.7 mm                                |
| Inductive Ignition Coil                    | Primary coil  | 0.55~0.75Ω                                  |
| Throttle Position Sensor Input Volt        |               | 5V ±0.1                                     |
| Fuel Pump                                  |               | About 2.0Ω                                  |
| Fuel Injector                              |               | 10.6Ω~15.9Ω                                 |
| Engine Temperature Sensor                  |               | 2.5kΩ~2.7kΩ(25℃)                            |
| Oxygen Sensor ( engine warming condition ) |               | 6.7 ~ 9.5Ω                                  |
| Crank Position Sensor                      |               | 96~144Ω                                     |
| Angle Detect Sensor                        |               | 0.4V~1.44V(normal)<br>3.7V~4.4V (fall down) |

## TROUBLESHOOTING

### No peak voltage

- Short circuit in engine stop switch or ignition switch wire.
- Faulty engine stop switch or ignition switch.
- Loose or poorly connected ignition control module connectors.
- Open circuit or poor connection in ground wire of the ignition control module.
- Faulty crank position sensor.
- Faulty ignition control module.

### Peak voltage is normal, but no spark jumps at the plug

- Faulty spark plug or leaking ignition coil secondary current.
- Faulty ignition coil.

## 15. IGNITION SYSTEM


### IGNITION COIL

#### REMOVAL

Remove the met-in box. (⇒2-3)

Remove the spark plug cap.

Disconnect the ignition coil wires and remove the ignition coil bolt and ignition coil.




Ignition Coil

#### INSPECTION

##### CONTINUITY TEST

Measure the resistance between the ignition coil primary coil terminals.

**Resistance:** 0.1~1.0Ω




Measure the secondary coil resistances with and without the spark plug cap.

##### Resistances:

(with plug cap) : 7~12KΩ

(without plug cap) : 3~5KΩ



\* Correctly operate the tester following the manufacturer's instructions.

## 15. IGNITION SYSTEM

### PULSER COIL INSPECTION

\* This test is performed with the stator installed in the engine.

Remove the frame body cover. (⇒2-3)  
Disconnect the A.C. generator connector.



Pulser Coil Coupler

Measure the pulser coil resistance between the blue/yellow and green wire terminals.

**Resistance:** 80~160Ω

Refer to page 14-6 for the A.C. generator removal.

### IGNITION TIMING INSPECTION

Remove the timing hole cap.

Timing Hole Cap



Warm up the engine and check the ignition timing with a timing light.  
When the engine is running at the ignition timing is correct if the "F" mark aligns with the index mark within  $\pm 2^\circ$ .

**Ignition Timing:** BTDC $28^\circ$ /4000rpm



"F" Mark

## 15. IGNITION SYSTEM


### A .C. GENERATOR INSPECTION

#### CRANK POSITION SENSOR INSPECTION

\* This test is performed with the stator installed in the engine.



Remove the seat and met-in box.  
Disconnect the Crank Position Sensor Wire Coupler.  
Measure the resistance between the blue/white and green/white wire terminals.

|                           |         |
|---------------------------|---------|
| Blue/Yellow ~ Green/White | 96~144Ω |
|---------------------------|---------|



Crank Position Sensor Wire Coupler

## 16. STARTING SYSTEM



# 16. STARTING SYSTEM

|                           |      |                     |      |
|---------------------------|------|---------------------|------|
| SERVICE INFORMATION ..... | 16-1 | STARTER MOTOR ..... | 16-2 |
| TROUBLESHOOTING .....     | 16-1 | STARTER RELAY.....  | 16-4 |

## SERVICE INFORMATION

### GENERAL INSTRUCTIONS

- The removal of starter motor can be accomplished with the engine installed.

### SPECIFICATIONS

| Item                       | Standard (mm) | Service Limit (mm) |
|----------------------------|---------------|--------------------|
| Starter motor brush length | 12.5          | 8.5                |

## TROUBLESHOOTING

### Starter motor won't turn

- Fuse burned out
- Weak battery
- Faulty ignition switch
- Faulty starter clutch
- Faulty front or rear stop switch
- Faulty starter relay
- Poorly connected, broken or shorted wire
- Faulty starter motor

### Lack of power

- Weak battery
- Loose wire or connection
- Foreign matter stuck in starter motor or gear

### Starter motor rotates but engine does not start

- Faulty starter clutch
- Starter motor rotates reversely
- Weak battery

## 16. STARTING SYSTEM

### STARTER MOTOR


#### REMOVAL

- \* Before removing the starter motor, turn the ignition switch OFF and remove the battery ground. Then, turn on the ignition switch and push the starter button to see if the starter motor operates properly.

Remove the motor from the box.

Remove the starter motor cable.

Remove the two starter motor mounting bolts and the motor.




Front Cover

Remove the waterproof rubber jacket and disconnect the starter motor cable connector.

#### DISASSEMBLY

Remove the two starter motor case screws, front cover, motor case and other parts.




Motor Case


Case Screws  
Commutator

#### INSPECTION

Inspect the removed parts for wear, damage or discoloration and replace if necessary. Clean the commutator if there is metal powder between the segments.



Check for continuity between pairs of the commutator segments and there should be continuity. Also, make a continuity check between individual commutator segments and the armature shaft. There should be no continuity.




## 16. STARTING SYSTEM

### STARTER MOTOR CASE CONTINUITY CHECK

Check to confirm that there is no continuity between the starter motor wire terminal and the motor front cover.

Also check for the continuity between the wire terminal and each brush and there should be continuity.


Replace if necessary.




Wire Terminal

Measure the length of the brushes.


**Service Limit:** 8.5mm replace if below



Check for continuity between the brushes. If there is continuity, replace with new ones.



Check if the needle bearing in the front cover turns freely and has no excessive play. Replace if necessary.  
Check the dust seal for wear or damage.



Dust Seal



## 16. STARTING SYSTEM

### ASSEMBLY

Apply grease to the dust seal in the front cover.

Install the brushes onto the brush holders.

Apply a thin coat of grease to the two ends of the armature shaft.

Insert the commutator into the front cover.



- \*
  - Be careful not to damage the brush and armature shaft mating surfaces.
  - When installing the commutator, the armature shaft should not damage the dust seal lip.

Install a new O-ring to the front cover.

Install the starter motor case, aligning the tab on the motor case with the tab on the front cover.

Tighten the starter motor case screws.

- \*
  - When assembling the front cover and motor case, slightly press down the armature shaft to assemble them.



### STARTER RELAY

#### INSPECTION

Remove the met-in box.

Remove the battery cover.

Remove the frame body cover. (⇒2-2)

Turn the ignition switch ON and the starter relay is normal if you hear a click when the starter button is depressed.

If there is no click sound:

- Inspect the starter relay voltage
- Inspect the starter relay ground circuit
- Inspect the starter relay operation

#### STARTER RELAY VOLTAGE INSPECTION


Place the motorcycle on its main stand.

Measure the voltage between the starter relay connector green/yellow wire (-) and engine ground.

Turn the ignition switch ON and the battery voltage should be normal when the brake lever is fully applied.

If the battery has no voltage, inspect the stop switch continuity and cable.


- \*
  - Turn to the DCV position for the voltage meter, then inspect the starter relay.




## 16. STARTING SYSTEM

### STARTER RELAY TEST

Remove the battery cover.  
Disconnect the 4P connector from the starter relay and remove the starter relay.




Connect the starter relay (D) terminal to the 12V battery positive (+) terminal and the relay (C) terminal to the battery negative (-) terminal. Check for continuity between the starter relay (A) and (B) terminals. The relay is normal if there is continuity.



### STARTER MOTOR INSTALLATION

Apply engine oil to the starter motor O-ring and install the starter motor.  
Tighten the two mounting bolts.  
Connect the starter motor cable connector.



# 17. LIGHTS/INSTRUMENTS/SWITCHES

17

|                           |      |                         |      |
|---------------------------|------|-------------------------|------|
| SERVICE INFORMATION ..... | 17-0 | IGNITION SWITCH.....    | 17-3 |
| TROUBLESHOOTING .....     | 17-0 | STOP SWITCHES/HORN..... | 17-4 |
| FUEL UNIT .....           | 17-1 | INSTRUMENTS .....       | 17-4 |
| HANDLEBAR SWITCHES.....   | 17-2 | HEADLIGHT/LIGHTS.....   | 17-5 |

## SERVICE INFORMATION

### GENERAL INSTRUCTIONS

- An electric tester is needed to measure or test the electric equipment.
- Be sure to use fuses and bulbs of the same specifications to avoid damage of electrical equipment.
- After installation of each switch, a continuity check must be performed. A continuity check can usually be made without removing the part from the motorcycle.

## TROUBLESHOOTING

### Lights do not come on when ignition switch is "ON"

- Burned bulb
- Faulty switch
- Broken wire
- Fuse burned out
- Weak battery
- Poorly connected or shorted wire
- Faulty winker

### Light dims

- Faulty ignition coil
- Wire or switch resistance too high
- Faulty regulator/rectifier

### Headlight does not change when dimmer switch is turn to Hi or Lo

- Faulty or burned bulb
- Faulty dimmer switch

### Fuel gauge pointer does not register correctly

- Disconnected wire or connector
- Broken wire
- Faulty float
- Faulty fuel unit
- Faulty instrument

### Fuel gauge pointer fluctuates or swings

- Loose wire connection
- Faulty fuel unit
- Faulty instrument

# 17. LIGHTS/INSTRUMENTS/SWITCHES


## FUEL UNIT

\* **No Smoking!**

### REMOVAL

Remove the met-in box. (⇒2-3)  
Remove the frame right side cover. (⇒2-4)  
Disconnect the fuel unit wire connector.  
Turn the fuel unit retainer counterclockwise to remove it.

\* Do not damage the fuel unit wire.




Remove the fuel unit.

\* Be careful not to bend or damage the fuel unit float arm.

### INSTALLATION

The installation sequence is the reverse of removal.


- \* Align the groove on the fuel unit with the tab on the fuel tank.
- \* Align the arrow on the retainer with the arrow on the fuel tank.
- \* Turn the retainer clockwise to secure it.



### INSPECTION

Remove the fuel unit.  
Measure the resistance between the fuel unit wire terminals with the float at upper and lower positions.

| Wire Terminals | Upper | Lower |
|----------------|-------|-------|
| G ~ Y/W        | 30Ω   | 686Ω  |
| G ~ L/W        | 566Ω  | 153Ω  |
| Y/W ~ L/W      | 599Ω  | 599Ω  |




### FUEL GAUGE INSPECTION

Connect the fuel unit wire connector and turn the ignition switch "ON".

\* Before performing the following test, operate the turn signals to determine that the battery circuit is normal.

Check the fuel gauge needle for correct indication by moving the fuel unit float up and down.

| Float Position | Needle Position |
|----------------|-----------------|
| Upper          | "F" (Full)      |
| Lower          | "E" (Empty)     |



### HANDLEBAR SWITCHES

#### INSPECTION

Remove the handlebar front cover. (⇒2-2)  
Disconnect the handlebar switch couplers and check for continuity between wire terminals. If there is any abnormality found, check each switch.

#### HEADLIGHT SWITCH(SUPER 8 50 E4)

| Color                                                                             | Black | Brown | Blue/White | Brown/White |
|-----------------------------------------------------------------------------------|-------|-------|------------|-------------|
| •                                                                                 | ○     |       |            |             |
|  | ○     | ○     |            | ○           |
|  | ○     | ○     | ○          |             |

\* Use the X1Ω range for test when using an electric tester.

#### STARTER SWITCH





| Color | Yellow/Red | Green |
|-------|------------|-------|
| FREE  |            |       |
| PUSH  | ○          | ○     |

#### DIMMER SWITCH

| Color                                                                               | White | Black | Blue |
|-------------------------------------------------------------------------------------|-------|-------|------|
|  | ○     | ○     |      |
|  |       | ○     | ○    |

#### TURN SIGNAL SWITCH

| Color | Gray | Light Blue | Orange |
|-------|------|------------|--------|
| R     | ○    | ○          |        |
| N     |      |            |        |
| L     | ○    |            | ○      |



## 17. LIGHTS/INSTRUMENTS/SWITCHES

### HORN SWITCH


| Color | Light Green                                                                       | Black                                                                             |
|-------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| FREE  |                                                                                   |                                                                                   |
| PUSH  |  |  |

### SWITCH REPLACEMENT

Remove the front covers. (⇒2-2)

Remove the handlebar front cover. (⇒2-2)

The installation sequence is the reverse of removal.



### IGNITION SWITCH


#### INSPECTION

Remove the front covers. (⇒2-2)

Disconnect the ignition switch wire coupler.

Check for continuity between the wire terminals.

| Color | Black                                                                               | Red                                                                                 | Black/Blue                                                                          | Green                                                                               |
|-------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| OFF   |                                                                                     |                                                                                     |   |   |
| ON    |  |  |                                                                                     |                                                                                     |
| LOCK  |                                                                                     |                                                                                     |  |  |



### IGNITION SWITCH REPLACEMENT


Remove the front covers. (⇒2-2)

Disconnect the ignition switch wire coupler.

Remove the two mounting bolts to remove the ignition switch decorative ring and holder.

Remove the two screws to remove the ignition switch from the ignition switch holder for replacement.

The installation sequence is the reverse of removal.





# 17. LIGHTS/INSTRUMENTS/SWITCHES

## STOP SWITCH

### INSPECTION

Remove the handlebar upper cover. (⇒2-2)  
 Disconnect the front stop switch wire coupler.  
 Check for continuity between the wire terminals when the front brake lever is applied. The switch is normal if there is continuity.  
 Disconnect the rear stop switch wire coupler.  
 Check for continuity between the wire terminals when the rear brake lever is applied.  
 The switch is normal if there is continuity.



Stop Switch Wire


## HORN

### INSPECTION

Remove the front covers. (⇒2-2)  
 Disconnect the horn wire coupler.  
 The horn is normal if it sounds when a 12V battery is connected across the horn wire terminals.

### REPLACEMENT


Disconnect the horn wire coupler.  
 Remove the two bolts attaching the horn.  
 Remove the horn.  
 The installation sequence is the reverse of removal.



Coupler

## INSTRUMENTS

Remove the handlebar front cover. (⇒2-2)  
 Remove the handlebar rear cover. (⇒2-2)  
 Disconnect the handlebar switch couplers.  
 Remove the three screws to remove the instruments.  
 Install a new horn in the reverse order of removal.



Instruments

Screws

## 17. LIGHTS/INSTRUMENTS/SWITCHES

### HEADLIGHT

#### REMOVAL


Remove the front cover(⇒2-3).  
Remove the headlight set.

\*

- Align the tab on the headlight with the groove on the handlebar cover.
- After installation, adjust the headlight beam.

#### REPLACEMENT

Headlight set need to be replaced as a set.  
The installation sequence is the reverse of removal.




### HEADLIGHT CONTROLLER

The Headlight is come on when the engine starts.

#### INSPECTION


Turn the ignition switch to “ON” Connect the multimeter (+) probe to the Black terminal and the multi-meter (-) probe to the Green terminal. The voltage is the battery voltage.

Starts the engine. Connect the multimeter (+) probe to the white/Blue terminal and the multi-meter (-) probe to the Green terminal. The voltage is the battery voltage.



### TAILLIGHT/STOPLIGHT/REAR TURN SIGNAL LIGHT/LICENSE LIGHT

Remove the body cover(⇒2-9).  
Remove the taillight set.





## 18. EVAPORATIVE EMISSION CONTROL SYSTEM

---

---

---

**18**

---

---

### EVAPORATIVE EMISSION CONTROL SYSTEM


---

**(Apply to models with evaporative emission control system )**


---

|                                                   |      |
|---------------------------------------------------|------|
| SCHEMATIC DRAWING -----                           | 20-1 |
| EVAPORATIVE EMISSION CONTROL SYSTEM FUNCTION----- | 20-2 |
| TROUBLESHOOTING-----                              | 20-2 |
| SERVICE INFORMATION -----                         | 20-3 |
| PERGE CONTROL VALVE -----                         | 20-4 |
| CHARCOAL CANISTER-----                            | 20-6 |

## SCHEMATIC DRAWING



Air Cleaner



Fuel Injector

Fuel tank cap

Throttle Body

Charcoal Canister/ Purge Control Valve

## 18. EVAPORATIVE EMISSION CONTROL SYSTEM

### EVAPORATIVE EMISSION CONTROL SYSTEM FUNCTION

#### FOREWORD:

The Evaporative Emission Control System is abbreviated to E.E.C. System. This device collects the fuel vapor from the fuel tank and then the fuel vapor is drawn into the engine for re-burning to avoid air pollution caused by the fuel vapor diffused into the air.

#### FUNCTION

| Item                | Purpose                                                                     | Function                                                                                                                                                                                                        |
|---------------------|-----------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Purge Control Valve | Control vaporized HC from fuel tank not to diffuse into the air.            | The charcoal canister absorbs vaporized HC from the fuel tank. When the engine is running and the purge control valve is open, the fuel vapor in the charcoal canister is drawn into the engine for re-burning. |
| Charcoal Canister   | Absorb and store the vaporized HC from the fuel tank and carburetor.        | The vaporized HC is absorbed in the charcoal canister and the specified volume of HC in the emission should not exceed 2g.                                                                                      |
| P.C.V. System       | Completely recover the HC from blow-by gas in the crankcase for re-burning. | Through the P.C.V. system, the blow-by gas from the crankcase is separated into fuel vapor and fuel and then drawn into the cylinder for re-burning.                                                            |

### TROUBLESHOOTING

#### Engine loses power or runs erratic at idle speed

1. Clogged P.C.V. system
2. Clogged air cleaner
3. Faulty purge control valve
4. Loose or broken E.E.C. system tubes

#### Engine idles or accelerates roughly

1. Faulty fuel cut-off valve
2. Faulty purge control valve
3. Clogged or faulty charcoal canister

# 18. EVAPORATIVE EMISSION CONTROL SYSTEM

## SERVICE INFORMATION

### GENERAL INSTRUCTIONS

- Do not smoke or allow flames or sparks near the working area.
- Note the locations of tubes for proper installation.
- Replace any damaged tube with a new one.
- Make sure to tighten the connector of each tube securely.


### TOOLS

- Vacuum pump — A937X — 014 — XXXX
- Pressure pump —

### SPECIFICATIONS

|                                     |         |
|-------------------------------------|---------|
| Purge control valve vacuum pressure | 45mm/Hg |
| Charcoal canister capacity          | 90cc    |


### A. LEAKAGE TEST PIPING DIAGRAM



# 18. EVAPORATIVE EMISSION CONTROL SYSTEM


## PURGE CONTROL VALVE REMOVAL

1. Remove the body cover.
2. Disconnect the purge control valve vacuum tube that goes to the throttle body and the tubes that go to the air cleaner and charcoal canister. Remove the charcoal canister/purge control valve.




## INSPECTION

Connect a vacuum pump to the purge control valve tube that goes to the air cleaner and apply vacuum pressure of 250mm/Hg. The specified vacuum must be maintained for one minute. Replace the purge control valve with a new one if vacuum is not maintained.




Connect a vacuum pump to the purge control valve tube that goes to the carburetor vacuum tube and apply vacuum pressure of 45mm/Hg. The specified vacuum must be maintained for one minute. Replace the purge control valve with a new one if vacuum is not maintained.



## PURGE CONTROL VALVE FLOW INSPECTION

1. Connect a vacuum pump to the purge control valve vacuum tube and apply vacuum pressure of 45mm/Hg.
2. Connect a pressure pump to the tube that goes to the charcoal canister and apply pressure. The flow must be over 9.4 liters per minute and replace the purge control valve with a new one if the specified flow is not reached.

\* To prevent damage to the purge control valve, do not use high air pressure sources. Use a hand operated pressure pump only.



## INSTALLATION

1. Install the purge control valve in the reverse order of removal.
2. Route and reconnect the purge control valve tubes properly and securely.

\* Be careful not to bend, twist or kink the tubes during installation.

# 18. EVAPORATIVE EMISSION CONTROL SYSTEM

## CHARCOAL CANISTER


### REMOVAL

1. Remove the front cover.
2. Disconnect the charcoal canister tubes that go to the fuel tank and purge control valve.
3. Remove the charcoal canister.



### INSPECTION

1. Plug the tube that goes to the fuel tank and plug the blow-by tube. Then connect a hose to the canister. Blow the hose with mouth. The charcoal canister is normal if air can be blown into it. If clogged, replace it with a new one.
2. Check the charcoal for cracks and replace if necessary.



### INSTALLATION

Install the charcoal canister in the reverse order of removal.

**\***

- The charcoal canister must be installed to its original position to avoid affecting its performance.
- Do not bend, twist or kink the tubes during installation.