



Pin	Color	Pin Function	ECU 端子	ECU 機能	ECU +S+端子	ECU +S+機能
1	B/L(1)	Wot	10	V/R	+5V ECU Out	ECU +5V輸出
2	V/G	Signal Gnd	11	-	Not Available	無適用
3	B(1)	O2 SENSOR	12	L/O	Not Available	無適用
4	V/B	TPS In	13	G/L	NTC Eng. In	エンジン温度入力
5	L/Y	CRANKSHAFT POSITION SENSOR	14	B/W	Eng. Off(KILL SW) In	エンジンOFF(殺車)入力
6	R/G/R	SPR SENSOR	15	B/R	RPM/ Singal Out	RPM(回転数)出力
7	P/G	MAP SW(normal close)	16	L/R	MAP(Multifunction Indicator Lamp)	MAP(多機能)出力
8	W/R	PMW Air Out	17	G/B	Power GND	電源接地
9	P/Y	Auto By Start	18	B/Y	IGN Out	点火線輸出

IG	E1/E2	BATT1	BATT2
ON			
OFF			
LOCK			
CORP. COLOR	B/W	G	R

  

START SW	ST	E
FREE		
PUSH		
CORP. COLOR	Y/R	G

LIGHT SW				
OFF	Q1	HL	TL	PO
N				
P-3rd				
N				
H				
CORP. COLOR	Y	L/W	BR	BR/W

WINKER SW		
WR	R	L
CORP. COLOR	GR	SB

DIMMER & PASSING SW			
HL	LO	HI	PASS
CORP. COLOR	L/W	W	L

HORN SW	
HO	BAT
CORP. COLOR	